

OPERATION AND PARTS MANUAL



SP3 “STREET PRO” PROFESSIONAL SLAB SAW 35 HP WISCONSIN DIESEL ENGINE MODELS SP303516, SP303520, SP303526 SP303530

Revision #3 (09/29/06)

To find the latest revision of this
publication, visit our website at:
www.multiquip.com



THIS MANUAL MUST COMPANY THE EQUIPMENT AT ALL TIMES.

PROPOSITION 65 WARNING



CALIFORNIA — Proposition 65 Warning


Engine exhaust and some of its constituents, and some dust created by power sanding, sawing, grinding, drilling and other construction activities contains chemicals known to the State of California to cause cancer, birth defects and other reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paints.
- Crystalline silica from bricks.
- Cement and other masonry products.
- Arsenic and chromium from chemically treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: **ALWAYS** work in a well ventilated area, and work with approved safety equipment, such as dust masks that are specially designed to filter out microscopic particles.

SILICOSIS / RESPIRATORY HAZARDS


! WARNING



SILICOSIS WARNING

Grinding/cutting/drilling of masonry, concrete, metal and other materials with silica in their composition may give off dust or mists containing crystalline silica. Silica is a basic component of sand, quartz, brick clay, granite and numerous other minerals and rocks. Repeated and/or substantial inhalation of airborne crystalline silica can cause serious or fatal respiratory diseases, including silicosis. In addition, California and some other authorities have listed respirable crystalline silica as a substance known to cause cancer. When cutting such materials, always follow the respiratory precautions mentioned above.

! WARNING



RESPIRATORY HAZARDS

Grinding/cutting/drilling of masonry, concrete, metal and other materials can generate dust, mists and fumes containing chemicals known to cause serious or fatal injury or illness, such as respiratory disease, cancer, birth defects or other reproductive harm. If you are unfamiliar with the risks associated with the particular process and/or material being cut or the composition of the tool being used, review the material safety data sheet and/or consult your employer, the material manufacturer/supplier, governmental agencies such as OSHA and NIOSH and other sources on hazardous materials. California and some other authorities, for instance, have published lists of substances known to cause cancer, reproductive toxicity, or other harmful effects.

Control dust, mist and fumes at the source where possible. In this regard use good work practices and follow the recommendations of the manufacturers or suppliers, OSHA/NIOSH, and occupational and trade associations. Water should be used for dust suppression when wet cutting is feasible. When the hazards from inhalation of dust, mists and fumes cannot be eliminated, the operator and any bystanders should always wear a respirator approved by NIOSH/MSHA for the materials being used.

Table of Contents

| | |
|--|-----------|
| PROPOSITION 65 WARNING | 1 |
| SILICOSIS /RESPIRATORY HAZARDS..... | 2 |
| PARTS ORDERING PROCEDURES | 6 |
| SAFETY..... | 7 |
| HAZARD SYMBOLS | 8 |
| GENERAL SAFETY WARNINGS | 11 |
| BLADE SAFETY | 13 |
| SAW TRANSPORTATION SAFETY | 14 |
| EMERGENCIES | 14 |
| MACHINE OPERATION AND SAFETY DECALS..... | 15 |
| SERIAL TAG | 16 |
| OPERATION | 17 |
| BEFORE STARTING..... | 17 |
| CONTROL PANEL | 18 |
| ENGINE POWER, CUTTING POWER & SHEAVE SIZE..... | 19 |
| INSTALLING THE BLADE, BLADE GUARD & BLADE FLANGE | 20 |
| REMOVING THE BLADE, BLADE GUARD & BLADE FLANGE..... | 21 |
| STACKING BLADES FOR WIDE CUTS | 22 |
| INSTALLING AND REMOVING THE BLADE GUARD..... | 23 |
| WATER SUPPLY AND CONTROL | 26 |
| HANDLEBARS..... | 27 |
| FUELING THE SAW | 28 |
| STARTING AND STOPPING THE ENGINE | 29 |
| POINTER ADJUSTMENT | 30 |
| RAISE – LOWER CONTROLS | 31 |
| SETTING THE DEPTH GAUGE & DEPTH STOP | 32 |
| DRIVE SYSTEM | 33 |
| NIGHT LIGHT | 36 |
| TRANSPORTATION TIE-DOWNS AND LIFT POINT | 37 |
| OPERATION ON A SLOPE OR INCLINE..... | 38 |
| FREEING A STUCK BLADE | 38 |
| DRAINING THE WATER SYSTEM..... | 39 |

| | |
|---|-----------|
| MAINTENANCE..... | 40 |
| REMOVABLE GUARDS AND ACCESS PANELS..... | 40 |
| BELTS AND PULLEYS | 41 |
| BLADE FLANGE REMOVAL/INSTALLATION | 45 |
| CIRCUIT BREAKERS | 50 |
| MAXIMUM CUT DEPTH ADJUSTMENT | 50 |
| LUBRICATION | 51 |
| ENGINE MAINTENANCE | 52 |
| RAISE-LOWER SYSTEM..... | 53 |
| CONTROL HANDLE ADJUSTMENT | 54 |
| HYDRAULIC SYSTEM | 55 |
| POSITRACTION ADJUSTMENT..... | 60 |
| EXPLANATION OF CODE IN REMARKS COLUMN..... | 61 |
| SUGGESTED SPARE PARTS..... | 62 |
| COMPONENT DRAWINGS..... | 63 |
| NAMEPLATE AND DECALS ASSY..... | 63 |
| DECK/GAUGE PANEL ASSY. | 65 |
| CONSOLE/SHEET METAL ASSY..... | 67 |
| ACCESS PANEL ASSY..... | 69 |
| FUEL TANK ASSY. | 71 |
| F-N-R CONTROL HANDLE ASSY..... | 73 |
| JOYSTICK MOUNTING ASSY..... | 75 |
| LIFT PUMP CIRCUIT ASSY..... | 77 |
| WATER SYSTEM ASSY. | 79 |
| DEPTH INDICATOR ASSY..... | 81 |
| HANDLE AND LIGHT ASSY..... | 83 |
| FRONT/REAR POINTER ASSY. | 85 |
| GAUGES AND CONTROLS ASSY..... | 87 |
| FRONT AXLE ASSY. | 89 |
| DEPTH STOP ASSY. | 91 |
| PLATFORM ASSY..... | 93 |
| DRIVE ASSY..... | 95 |
| BLADESHAFT AND MOUNTING ASSY. | 97 |
| POSITRACTION ASSY..... | 99 |

| | |
|---|------------|
| PULLEY AND V-BELT ASSY. | 101 |
| BATTERY ASSY..... | 103 |
| ENGINE BRACKETS ASSY..... | 105 |
| ENGINE INSTALLATION ASSY..... | 107 |
| BLADEGUARD ASSY..... | 109 |
| OPTIONAL WATER PUMP KIT ASSY. | 111 |
| COLLAR PULLER ASSY..... | 113 |
| SEAL SLEEVE PULLER/SEAL INSTALLATION TOOL | 115 |
| BUSHING EXTENSION KITS | 117 |
| ELECTRIC SCHEMATIC | 119 |
| SPECIFICATIONS..... | 120 |

PARTS ORDERING PROCEDURES

Ordering parts has never been easier!

Choose from three easy options:

www.multiquip.com



Order via Internet (Dealers Only):

Order parts on-line using Multiquip's SmartEquip website!

- View Parts Diagrams
- Order Parts
- Print Specification Information



If you have an MQ Account, to obtain a Username and Password, E-mail us at: parts@multiquip.com.

To obtain an MQ Account, contact your District Sales Manager for more information.

Go to www.Multiquip.com and click on



to log on and save!

Fax your order in and qualify for a **5% Discount** on *Standard orders* for all orders which include complete part numbers.*

Note: Discounts Are Subject To Change



Order via Fax (Dealers Only):

All customers are welcome to order parts via Fax.

Domestic (US) Customers dial:

1-800-6-PARTS-7 (800-672-7877)

Fax your order in and qualify for a **3% Discount** on *Standard orders* for all orders which include complete part numbers.*

Note: Discounts Are Subject To Change



Order via Phone:

Domestic (US) Dealers Call:

1-800-427-124

Non-Dealer Customers:

Contact your local Multiquip Dealer for parts or call 800-427-1244 for help in locating a dealer near you.



International Customers should contact their local Multiquip Representatives for Parts Ordering information.

When ordering parts, please supply:

- Dealer Account Number
- Dealer Name and Address
- Shipping Address (if different than billing address)
- Return Fax Number
- Applicable Model Number
- Quantity, Part Number and Description of each Part
- Specify Preferred Method of Shipment:
 - ✓ Fed Ex/UF
 - ✓ Priority On
 - Ground
 - Next Day
 - Second/Third Day
 - ✓ DHL
 - ✓ Truck



NOTE


Unless otherwise indicated by customer, all orders are treated as *Standard Orders* and will ship within 24 hours. We will make every effort to ship *Air Shipments* the same day the order is received, if received prior to 2PM PST. *Stock Orders* must be noted on fax or web order form.

WE ACCEPT ALL MAJOR CREDIT CARDS!



SAFETY




FOR YOUR SAFETY AND THE SAFETY OF OTHERS!

| | |
|--|--|
|  NOTE | <p>This Owner's Manual has been developed to provide instructions for the safe and efficient operation of the Multiquip SP-3035 CONCRETE SAW. For engine maintenance information, please refer to the engine manufacturers' instructions for data relative to its safe operation.</p> <p><u>Before using this CONCRETE SAW, ensure that the operating individual has read and understands all instructions in this manual.</u></p> |
|--|--|

Safety precautions should be followed at all times when operating this equipment. Failure to read and understand the Safety Messages and Operating Instructions could result in injury to yourself and others.






SAFETY MESSAGE ALERT SYMBOLS

The three (3) Safety Messages shown below will inform you about potential hazards that could injure you or others. The Safety Messages specifically address the level of exposure to the operator, and are preceded by one of three words: DANGER, WARNING, or CAUTION.







| | |
|--|--|
|  DANGER | <p>DANGER: You WILL be KILLED or SERIOUSLY injured if you DO NOT follow directions.</p> |
|  WARNING | <p>WARNING: You CAN be KILLED or SERIOUSLY injured if you DO NOT follow directions.</p> |
|  CAUTION | <p>CAUTION: You CAN be injured if you DO NOT follow directions.</p> |

Potential hazards associated with SP-3035 Concrete Saw operation will be referenced with "*Hazard Symbols*" which appear throughout this manual, and will be referenced in conjunction with Safety "*Message Alert Symbols*".


HAZARD SYMBOLS


| | |
|---|--|
|  <p>Lethal Exhaust Gases</p> | <p>Engine exhaust gases contain poisonous carbon monoxide. This gas is colorless and odorless, and can cause death if inhaled. NEVER operate this equipment in a confined area or enclosed structure that does not provide ample free flow of air.</p> |
|  <p>Explosive Fuel</p> | <p>Gasoline is extremely flammable, and its vapors can cause an explosion if ignited. DO NOT start the engine near spilled fuel or combustible fluids. DO NOT fill the fuel tank while the engine is running or hot. DO NOT overfill the tank, since spilled fuel could ignite if it comes into contact with hot engine parts or sparks from the ignition system. Store fuel in approved containers, in well-ventilated areas and away from sparks and flames. NEVER use fuel as a cleaning agent.</p> |
|  <p>Burn Hazards</p> | <p>Engine components can generate extreme heat. To prevent burns, DO NOT touch these areas while the engine is running or immediately after operations. NEVER operate the engine with heat shields or heat guards removed.</p> |
|  <p>Rotating Parts</p> | <p>NEVER operate equipment with covers, or guards removed. Keep fingers, hands, hair and clothing away from all moving parts to prevent injury.</p> |
|  <p>Accidental Starting</p> | <p>ALWAYS place ON/OFF switch to the OFF position, remove key and/or disconnect the spark plug leads before servicing the engine, equipment, or supporting components. Ground the lead to prevent sparks that could ignite a fire.</p> |

HAZARD SYMBOLS


| | |
|--|---|
|  <p>Over Speed</p> | <p>NEVER tamper with factory settings of engine governor or speed settings. Ensure the proper Speed Kits are installed to safely support the prescribed RPM settings for diamond blade operations.</p> |
|  <p>Guards and Covers in Place</p> | <p>NEVER operate the saw without blade guards and covers in place. Adhere to safety guidelines ANSI American National Standards Institute, OSHA, and/or other applicable local regulations.</p> |
|  <p>Rotating Blade</p> | <p>Rotating Blade can cut, tear, and crush. Keep hands and feet clear.</p> |
|  <p>Respiratory Hazard</p> | <p>ALWAYS wear approved respiratory protection.</p> |
|  <p>Sight & Hearing Hazard</p> | <p>ALWAYS wear approved eye and hearing protection.</p> |
|  <p>Crush Hazard</p> | <p>CRUSH AND PINCH HAZARD Keep hands and feet clear.</p> |


HAZARD SYMBOLS

| | |
|---|---|
|  <p>Skin Injection Hazard</p> | <p>NEVER use your hand to find hydraulic leaks. Use a piece of wood or cardboard. Hydraulic fluid injected into the skin must be treated by a knowledgeable physician immediately or severe injury or death can occur.</p> |
|---|---|

| | |
|--|---|
|  <p>NOTE</p> | <p>Text set off like this presents clarifying information, specific instructions or commentary designed to help prevent damage to your saw, other property, or the environment.</p> |
|--|---|

Other important messages are provided throughout this manual to help prevent damage to your concrete saw, other property, or the surrounding environment.

| | |
|---|---|
|  <p>CAUTION</p> | <p>Equipment Damage Message</p> <p>Other important messages are provided throughout this manual to help prevent damage to your concrete saw, other property, or the surrounding environment.</p> |
|---|---|

| | |
|--|---|
|  <p>NOTE</p> | <p>This <i>concrete saw</i>, other property, or the surrounding environment could be damaged if you do not follow instructions.</p> |
|--|---|

General Safety Warnings

Most accidents involving product operation, maintenance and repair are caused by failure to observe basic safety rules and precautions. Accidents can often be avoided by recognizing potentially hazardous situations before an incident occurs.



WARNING

- Before operating the saw, make sure all protective guards are securely in place. All saws are supplied with a blade guard, collar guard and belt guard.
- Whenever necessary, replace operation and safety decals if they become difficult to read
- Verify the engine start switch is set to the OFF position before installing a blade.
- Make sure the operator knows how to turn the engine OFF in case of an emergency.
- Do not go near rotating parts (blades, belts, pulleys or wheels) while engine is running.
- Muffler and exhaust gases are extremely hot. Stay clear of muffler and exhaust gases. Allow these parts to cool before servicing the saw.
- Stay clear of the saw while it is being hoisted.
- Anytime the saw is lifted onto its nose, or tilted fully back, for maintenance access, the high end **MUST** be blocked up to prevent the possibility of crush injury!
- Allow the engine to cool before adding fuel or performing service and maintenance functions. Contact with **HOT** components can cause serious burns.
- Never operate the saw in any enclosed or narrow area where free flow of air is restricted. If the airflow is restricted it will cause serious damage to the saw's engine and may cause injury to people. Remember the saw's engine gives off **DEADLY** carbon monoxide gas.
- **ALWAYS** refuel in a well-ventilated area; away from sparks and open flame. Avoid "topping off" the filler port as spills can result.
- **ALWAYS** use extreme caution when working with flammable liquids. When refueling, **STOP** the engine and allow it to cool.
- **NEVER** smoke around or near the machine. Fire or explosion could result from fuel vapors, or if fuel is spilled on a **HOT** engine.
- **NEVER** operate the saw in an explosive atmosphere where fumes are present or near combustible materials. An explosion or fire could result causing severe bodily harm or even death.
- **NEVER** use fuel as a cleaning agent.



General Safety Warnings




WARNING

- ALWAYS read, understand, and follow procedures in the Operator's Manual before attempting to operate the equipment.
- Be sure the operator is familiar with proper safety precautions and operating techniques before using the saw.
- Make sure the operating area is clear before starting the engine.
- Maintain this equipment in a safe operating condition at all times
- Keep the saw clean. It will work better and last longer
- Use proper blades and follow the blade manufacturer's recommendations. Match blade rpm (Spindle rpm) to recommended blade surface feet per minute (SFPM).
- Tighten the 5/8" blade-mounting bolt to 100-125 foot-lbs. torque.
- Turn engine OFF prior to fueling the saw!
- Start engine with the joystick in NEUTRAL to prevent unexpected saw movement.
- Do not leave saw unattended while engine is running.
- Do not start engine on a sloping surface to prevent unexpected loss of control.
- Do not park or leave saw unattended on a slope - the saw can roll when the engine is OFF. Block the unit when leaving.
- If the saw must be parked on a slope, turn it across the angle of the slope, to prevent accidental downhill movement.
- Prior Always store equipment properly when not being used. Equipment should be stored in a clean, dry location out of the reach of children. When storing the saw in freezing weather, blow out water lines to prevent damage to components in the water delivery system.
- Prior to service, level the frame surface.
- Do not over tighten the Spindle drive belt
- Turn on water flow prior to starting the engine, to prevent damage to the impeller of a belt-driven water pump.
- Don't pollute! Waste oils and other chemicals must be disposed of in a manner consistent with local and state environmental protection regulations.








BLADE SAFETY

| | |
|--|---|
|  <p>WARNING</p> | <ul style="list-style-type: none">▪ ALWAYS inspect diamond blades before each use. The blade should exhibit no cracks, dings, or flaws in the steel centered core and/or rim. Center (arbor) hole must be undamaged and true.  <ul style="list-style-type: none">▪ Examine blade flanges for damage, excessive wear and cleanliness before mounting blade. Blade should fit snugly on the shaft and against the inside/outside of the saw.▪ Only cut the material that is specified by the blade. Read the specifications of the blade to ensure the proper tool has been matched to the material being cut.▪ ALWAYS keep blade guards in place. Exposure of the blade must not exceed 180 degrees.▪ Ensure that the blade does not come into contact with the ground or surface during transportation. DO NOT drop the blade on the ground or surface.▪ The engine governor is designed to permit maximum engine speed in a no-load condition. Speeds that exceed this limit may cause the blade to exceed the maximum safe allowable speed.▪ Ensure that the blade is mounted for proper operating direction. |
|--|---|

SAW TRANSPORTATION SAFETY

| | |
|--|---|
|  WARNING | <ul style="list-style-type: none"> ▪ Use appropriate lifting equipment to ensure the safe movement of the saw. ▪ DO NOT use the handle bars and/or front pointer as lifting points. ▪ NEVER attempt to tow the untrailerred saw behind a vehicle. ▪ NEVER transport the saw with the blade mounted. |
|--|---|

EMERGENCIES

| | |
|--|--|
|  WARNING | <ul style="list-style-type: none"> ▪ ALWAYS know the location of the nearest fire extinguisher. ▪ ALWAYS know the location of the nearest first aid kit. ▪ In emergencies always know the location of the nearest phone or keep a phone on the job site. <p>Know the phone numbers of the nearest ambulance, doctor, and fire department. Knowing this information is invaluable in the case of an emergency and could keep a serious situation from becoming a tragic one.</p> |
| |       |

MACHINE OPERATION AND SAFETY DECALS

The Multiquip SP-3035 Saw is equipped with a number of operation and safety decals. Should any of these decals become unreadable, replacements can be obtained from your dealer.




Fig. 1 — Decals

Serial Tag





Fig. 2 — Serial Tag

| | |
|--|---|
|  NOTE | <p>For future reference, fill in the model number and serial number of your saw in the space above.</p> |
|--|---|

The serial tag contains the model number and serial number of the saw. This information details all parts that were included with the saw when it was shipped from the factory, as well as the date of manufacture.

Record your **ENGINE** model number, spec. number and serial number here:

| MODEL NO. | SPEC. NO. | SERIAL NO. |
|-----------|-----------|------------|
| | | |

The serial tag is bonded to the inside panel of the console.








Fig. 3 — Serial Number Locations

OPERATION

Before Starting

| | | |
|---|---|---|
|  |  | Walk around the saw and ensure that all guards and panels are properly installed. |
| |  | Wear eye and hearing protection. |
| |  | Wear protective clothing. |

1. Check engine and hydraulic oil.
2. Verify the proper-sized blade guard is fully installed on the blade guard mounting tab.
3. Adjust handlebars for best operator control.
4. If a *belt driven water pump* is installed, turn on the water flow *before* starting the engine.




Fig. 4 — Guards & Panels

Control Panel






Fig. 5 — The Control Panel

Engine Power, Cutting Power & Sheave Size

| | | |
|--|---|---|
|  WARNING |  | <p>NEVER tamper with factory settings of engine governor or speed settings. Ensure the proper Speed Kits are installed to safely support the prescribed RPM settings for diamond blade operations.</p> |
|--|---|---|

Blade Size & Configuration per Model





The SP-3035 is available in four Blade Speed configurations. The following chart shows the various configurations for each model.

| Blade Size | Model | Engine RPM No Load | Spindle RPM No Load | Governor Setting (Hole Number) | Ratio Kit | Engine Pulley Part Number | Engine Pulley Size | Spindle Pulley Part Number | Spindle Pulley Size | Surface Feet Per Minute |
|------------|---------|--------------------|---------------------|--------------------------------|-----------|---------------------------|--------------------|----------------------------|---------------------|-------------------------|
| 16" | Q303516 | 3000 | 3000 | 12 | 25603 | 540000 | 3.8" | 540006 | 3.8" | 12566 |
| 20" | Q303520 | 2520 | 2800 | 9 | 25849 | 540070 | 3.6" | 540066 | 4.0" | 13195 |
| 26" | Q303526 | 2000 | 2800 | 7 | 35103 | 540012 | 3.0" | 540065 | 4.2" | 13614 |
| 30" | Q303530 | 1773 | 2600 | 5 | 35104 | 540012 | 3.0" | 540049 | 4.4" | 13923 |

When choosing a blade for your cutting conditions, follow the blade manufacturer's recommendations. Match blade RPM (Spindle RPM) to the recommended blade Surface Feet Per Minute (SFPM).


| SFPM | 12" dia. RPM | 14" dia. RPM | 16" dia. RPM | 18" dia. RPM | 20" dia. RPM | 24" dia. RPM | 26" dia. RPM | 30" dia. RPM |
|--------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| 8,000 | 2546 | 2183 | 1910 | 1698 | 1528 | 1273 | 1175 | 1019 |
| 8,500 | 2706 | 2319 | 2029 | 1804 | 1623 | 1353 | 1249 | 1082 |
| 9,000 | 2865 | 2456 | 2149 | 1910 | 1719 | 1432 | 1322 | 1146 |
| 9,500 | 3024 | 2592 | 2268 | 2016 | 1814 | 1512 | 1396 | 1210 |
| 10,000 | 3183 | 2728 | 2387 | 2122 | 1910 | 1592 | 1469 | 1273 |
| 10,500 | 3342 | 2865 | 2507 | 2228 | 2005 | 1671 | 1543 | 1337 |
| 11,000 | 3501 | 3001 | 2626 | 2334 | 2101 | 1751 | 1616 | 1401 |
| 11,500 | 3661 | 3138 | 2745 | 2440 | 2196 | 1830 | 1690 | 1464 |
| 12,000 | 3820 | 3274 | 2865 | 2546 | 2292 | 1910 | 1763 | 1528 |
| 12,500 | 3979 | 3410 | 2984 | 2653 | 2387 | 1989 | 1836 | 1592 |
| 13,000 | 4138 | 3548 | 3104 | 2759 | 2483 | 2069 | 1910 | 1655 |

Installing the Blade, Blade Guard & Blade Flange

| | | |
|--|---|---|
|  WARNING |  | Remain Clear of all parts of saw while installing blade to prevent crush injury or death. |
| |  | Verify the engine start switch is OFF before installing blade. |
| |  | Tighten the 5/8" blade-mounting bolt to 100-125 foot-pounds torque. |

The blade can be mounted on either side of the saw to accommodate different cutting jobs.

1. Raise the saw so that the blade will clear the ground when installed.
2. Verify that blade flanges are clean and undamaged.
3. Insert the bushing and mounting bolt through the outer flange and blade.
4. Align flange pin through the blade into the inner flange.
5. Tighten the 5/8" mounting bolt to **100-125 foot-pounds** of torque.

| | |
|---|--|
|  NOTE | The blade mounting bolt on the right side of the saw (as viewed from the operator's position) has a left hand-thread, while the blade-mounting bolt on the left side of the saw has a right-hand thread. |
|---|--|









Fig. 6 — Blade Components

Removing the Blade, Blade Guard & Blade Flange

| | | |
|--|---|---|
|  WARNING |  | Remain Clear of all parts of saw while installing blade to prevent crush injury or death. |
| |  | Verify the engine start switch is OFF before installing blade. |
| |  | Tighten the 5/8" blade-mounting bolt to 100-125 foot-pounds torque. |

1. Raise the saw so that the blade will clear the ground.
2. Remove blade guard. See fig. 7
3. Remove the mounting bolt from the outer flange and bushing.
4. Remove blade, outer flange and bushing simultaneously.
5. Reinstall the flange bushing, outer flange and mounting bolt.
6. Tighten the 5/8" mounting bolt to **75 foot-pounds** of torque.

| | |
|---|--|
|  NOTE | The blade mounting bolt on the right side of the saw (as viewed from the operator's position) has a left hand-thread, while the blade-mounting bolt on the left side of the saw has a right-hand thread. |
|---|--|








Figure 7. Blade Guard Removal

Stacking Blades for Wide Cuts

| | | |
|---|---|---|
|  WARNING |  | Remain Clear of all parts of saw while installing blade to prevent crush injury or death. |
| |  | Verify the engine start switch is OFF before installing blade. |
| |  | Tighten the 5/8" blade-mounting bolt to 100-125 foot-pounds torque. |

Combining (stacking) blades to make wide cuts **requires** an optional Bushing Extension Kit.

- Kit #18502 allows blade stacking from .375" to .75" thickness.
- Kit #18501 allows blade stacking from .75" to 1.125" thickness.

1. Ensure on/off switch is off. See Fig. 5 or Fig. 15
2. Remove the existing blade. See Removing the Blade Fig. 7
3. Replace the standard Flange Bushing, Flange Pin, and Mounting Bolt that came with the saw with the longer Bolt, Pin and Bushing which comes with the Kit.
4. Insert the Bushing and Mounting Bolt through the Outer Flange and Blades. The longer bushing and bolt allow blades to be stacked together.
5. Align the Flange Pin through the stack of Blades into the Inner Flange.
6. Tighten the 5/8" Mounting Bolt to 100-125 foot-pounds of torque.
7. Install blade guard.







Fig. 8 — Blade Stacking

Installing and Removing the Blade Guard

Blade Guards for the SP-3035 concrete saw can be installed on either side of the saw.

| | | |
|--|---|---|
|  WARNING |  OFF | Verify the engine start switch is OFF before installing blade. |
| |  | Remain clear of all parts of saw while installing blade to prevent crush injury or death. |

Installing the Blade Guard

1. Ensure on/off key is off. See Fig. 5 or Fig. 15
2. Slide the Blade Guard Mounting Clip onto the Guard Mounting Tab on the frame.
3. Connect the water delivery hose to the Blade Guard.
4. Ensure that the water tubes are pointed toward the water distribution grooves in the Blade Collars. See Fig. 10
5. Make sure the front-hinged section of the Blade Guard is fully closed before use.




Fig. 9 — The Blade Guard installed

Removing the Blade Guard

During use, the Blade Guard can become tight on the tapered mounting tab. To loosen it, wiggle the Rear Blade Guard Handle up and down, while lifting with the Top Handle.

Blade Guard Water Supply

Verify that the water hose on the saw is connected to the Blade Guard and that the water pipes are pointed into both Blade Collars.



NOTE

Make sure that the outlets of the water tubes point toward the lower portion of the blade collars, aimed at the delivery ports, for proper water delivery to the blade.




Fig. 10 — Water Tubes and the Blade Collar

Installing the Flange Guard

The Flange Guard provides protection from the Blade Flange not in use.

1. Verify that the unused Blade Flange is secured to the Spindle by tightening the mounting bolt.
2. Slide the Flange Guard onto the Guard Mounting Tab on the frame.




Fig. 11 — The Flange Guard, Installed

Water Supply and Control



WARNING

To prevent damage to the impeller of a *belt driven water pump*, do not run the engine with the water pump switch on, unless the water supply is connected and water is flowing.

When storing the saw during freezing weather, blow out the water lines to prevent damage to the water delivery system.

Connect the job water hose to the water inlet fitting on the left side of the saw.

Verify that the water hose on the saw is connected to the Blade Guard and that the water delivery tubes are pointed into both lower Blade Flanges.

The yellow lever on the control panel regulates water flow volume.

If the saw is equipped with an optional water pump, the ON/OFF switch is on the control panel next to the water flow control valve.



NOTE

Because of the water delivery efficiency of the 24-port blade flanges, these saws use less water for blade cooling and flushing than other saws.




Fig. 12 — The Water Supply System

Handlebars

The handlebars are adjustable to three different angles, for optimum operator control, and can also be slid fully inward for storage. Once handlebars are adjusted, lock them into position by tightening the lock knob on each side.

Using the handlebars in position #2 or #3, when employing larger diameter blades reduces the need to bend over and the effort required by the operator to maneuver the unit.




Fig. 13 — Handlebar Positions






NOTE

Using the handlebars in position #2 or #3 when employing larger diameter blades, reduces the need to bend over, and reduces the effort required by the operator to maneuver the saw.

Fueling the Saw

The 3000 Series saws feature a five-gallon clear molded plastic fuel tank with a sight gauge, central drain, and shutoff valve. The gas tank cap is located at the front of the saw.

| | | |
|--|---|--|
|  WARNING |  | <p>To prevent damage to the impeller of a <i>belt driven water pump</i>, do not run the engine with the water pump switch on, unless the water supply is connected and water is flowing.</p> <p>When storing the saw during freezing weather, blow out the water lines to prevent damage to the water delivery system.</p> |
|--|---|--|

| | |
|--|---|
|  CAUTION | <p>Use 90+ Octane Unleaded Gasoline Only</p> |
|--|---|




Fig. 14 — Fueling the Saw

Starting and Stopping the Engine



WARNING

Do not leave the saw unattended while the engine is running.
Do not start, park, or leave the saw unattended on a slope.



CAUTION

- If the saw has an optional water pump, *do not* run the saw dry with the water pump switch ON — otherwise the pump impellers *will* be damaged.
- In normal operation, *do not stop the engine abruptly when hot!* Reduce the throttle to idle and allow the engine to run one or two minutes before turning the ignition switch off.

1. Check Oil levels in engine and hydraulic system
2. If water pump option is installed, start water supply to blade.
3. Move the speed control joystick to **NEUTRAL** position.
4. Set the throttle to ½ open
5. Turn on/off switch to “**START**” position and at the same time pull out choke cable only sufficient to start the engine. Release choke cable after engine starts. Re-choke if engine tends to stall. When engine starts, release switch to “**RUN**” position. Allow engine to warm up before applying load.
6. Ensure that water lines are attached and water is flowing to the saw.
7. Set the throttle to the recommended engine RPM to match the recommended blade speed of the attached blade.
8. Lower the blade to the cut depth.
9. Move the joystick **FORWARD** to advance the cut.
10. **When finished cutting, allow the engine to cool down by running at 1000 to 1200 RPM for 3 to 5 minutes depending on how hot the engine has been.** This will reduce the chance of engine damage or vapor lock.



WARNING

Make sure the operator knows how to turn the engine off in case of an emergency.
Do not go near rotating parts (blade, belts, pulleys, or wheels) while the saw is running.

To stop the engine, turn the “ON-OFF” switch to the “OFF” position.




Fig. 15 — ON/OFF Switch Location

Pointer Adjustment

1. Lower the front pointer assembly: Release the rope from the cam cleat, and rotate the pointer forward into position.
2. Adjust the pointer rod by loosening the lock knob: Once the pointer rod is set to the cut line, tighten the lock knob.
3. Adjust the rear pointer to the cut line: Loosen the lock bolt, position the pointer rod, and tighten the lock bolt.
4. To raise the front pointer assembly, pull back and up on the pointer cable.
5. Secure the pointer assembly in the desired raised position by locking the cable between the jaws of the cam cleat.




Fig. 16 – Pointer Adjustment

Raise - Lower Controls

This saw uses a 12-volt hydraulic pump and cylinder to raise and lower the blade. Controls are located on the speed control joystick handle.




Fig. 17 — Joystick Handle

1. To plunge the blade, depress the button on the outer end of the handle.
2. To raise the blade, depress the button on the forward side of the handle.

See the Maintenance section of this manual for a diagram of the Raise-Lower System components.

Setting the Depth Gauge & Depth Stop

The 3000 Series saws use a cable-controlled Depth Gauge and mechanical Depth Stop to lock the blade at the desired cut depth. See Fig. 18.

Setting the Depth Gauge

1. Lower the blade until it just touches the cutting surface.
2. Turn the Depth Gauge dial to zero.

The Depth Gauge will show the depth of cut. It should not be necessary to readjust the Depth Indicator until a different diameter of blade is installed.

Setting the Depth Stop

1. Lower the blade into the cut until the desired cutting depth is achieved.
2. Turn the Depth Stop Crank clockwise to take slack out of the Depth Stop.

To increase cutting depth, turn the Depth Stop Crank counter-clockwise. To reduce cutting depth, turn the Depth Stop Crank clockwise.




Fig. 18 — Setting the Depth Gauge and Depth Stop

Drive System

The 3000 Series saws have a cable-controlled Hydro-Gear hydrostatic powered transaxle with fully adjustable F-N-R (Forward-Neutral-Reverse) speed adjustment via a joystick control handle. The system utilizes a remote oil filter. There are no chains, sprockets or gearboxes requiring daily service.

The 3000 Series saws can travel at speeds up to 250 feet per minute.




Fig. 19 — The Drive System

Drive System Controls

The control handle controls FORWARD-NEUTRAL-REVERSE (F-N-R) speeds and the raising and lowering of the saw. To increase forward speed, slowly move the joystick FORWARD. Pulling the joystick backward decreases saw speed, and when the joystick passes NEUTRAL the saw moves into REVERSE. Reverse speed is also controlled by the position of the joystick.

Although not a true “free wheeling” mode, the Drive Disengage handle, when pulled, allows the saw to be freely moved when the engine is not running.

DO NOT DISENGAGE WHILE ENGINE IS RUNNING.




Fig. 20 — Drive System Controls



WARNING

Start the engine with the Forward-Neutral-Reverse Control in NEUTRAL to prevent unexpected saw movement.

Positraction

Positraction, when ON, locks both drive wheels together for straight-line movement. It is recommended for all cutting and is especially helpful on uneven surfaces, and when loading and unloading the saw.

1. Move the Positraction lever to "ON" (positraction engaged) to lock both drive wheels.
2. To unlock the drive wheels for easy maneuverability and turning, move the Positraction lever to OFF.



NOTE

See the Maintenance Section for instructions on aligning the wheels to correct pulling to the right or left.




Fig. 21 — The Positraction System

Transaxle

The hydrostatic-powered transaxle has no chains, sprockets or gearboxes to service. There is a simple cable control for forward-reverse motion, and a single drive belt from the engine to power the transaxle.




Fig. 22 —Transaxle

Night Light

The optional night light can be used on either side of the saw, and can be extended and rotated for best illumination of the cutting area. Once the light is aimed, lock it in position by tightening the lock knob. The light can be removed for storage by loosening the lock knob, disconnecting the light cord plug and sliding the light bar out of the saw.




Fig. 23 — Night Light

Transportation Tie-downs and Lift Point

Tie-downs

The saw is provided with holes at each corner of the lower frame for easy tie-down during transportation. *The saw **MUST** be tied down whenever it is being transported.*




Fig. 24 – Tie-down Points

Lift Point

The convenient single point for raising the saw with a hoist is located on top of the engine.






Fig. 25 – Lift Point

| | | |
|--|---|---|
|  <p>WARNING</p> |  | <p>To avoid possible injury, stay clear of the saw while it is being hoisted.</p> <p>To avoid possible damage to the saw, use approved rigging when hoisting the saw.</p> |
|--|---|---|

Operation on a Slope or Incline

Never operate, cut, or face the saw down a slope or incline. The weight of the saw will shift to the front wheels allowing the rear wheels to skid or come completely off the ground. This allows the saw to free wheel and possibly cause a runaway condition.

Always remove the blade when transporting or moving the saw outside of the cutting area. Use the following procedures for loading and unloading the saw.

Using Inclined Ramps to Load and Unload the Saw

Loading UP a Ramp

1. Make sure ramps are of sufficient strength and width to adequately support and load saw. Ensure the slope of the ramp is gentle enough to load the saw.
2. Remove blade from Spindle if installed.
3. Ensure saw is warmed up to decrease the chance of the engine stalling.
4. Run the engine between $\frac{3}{4}$ and full throttle.
5. Raise front of saw only enough to get started up ramp. As the rear wheels approach the ramp, start lowering the front end of the saw. Raise and lower the front end as necessary to keep the blade flanges off trailer deck.
6. Turn engine off, lower saw fully.
7. Tie the saw down securely for transit.

Unloading DOWN a Ramp

Unload the saw by backing it down the ramp. Never use a ramp with too great a slope as to create an unsafe loading condition. Use the techniques stated in the steps above to clear the ramp while keeping the front of the saw as close to the ramp as possible while backing it down. Never unload with the saw front facing downward on a ramp.

Freeing a Stuck Blade

The only acceptable method for freeing a stuck blade is to remove the saw from the stuck or pinched blade. DO NOT try to get the blade unstuck using the Raise/Lower system or by lifting the saw by the lifting bale, etc.

- Ensure ignition switch is turned off
- Remove blade guard
- Remove blade mounting bolt and outer flange
- Maneuver saw away from blade
- Make a parallel cut next to blade to free blade.

If an attempt is made to start the saw with the blade pinched, the starter will suffer damage. If an attempt is made to use the lift pump to raise the saw to free the blade, the lift motor and front axle could be damaged. If an attempt is made to lift the saw and blade out of the cut utilizing equipment such as a loader or back hoe, the saw frame and axle are likely to be damaged.



CAUTION

If the Water System is not drained when the saw is not in use and temperatures fall below 32°F, damage may occur to optional water pumps and/or oil coolers.

Draining the Water System

When low temperatures fall below 32°F:

1. If the saw is equipped with an optional Water Pump, open the drain petcock on the pump and allow the pump to drain.
2. With the engine running, turn the water pump switch on for a few seconds to purge water remaining inside the pump body.
3. Tilt the saw up and back, to allow water to drain.
4. Tilt the saw forward, to allow water to drain again.

If an air compressor is available, blow out the system by applying compressed air to the Water Inlet

MAINTENANCE

This saw has many service-saving features, such as fully enclosed oil bath lubricated Spindle bearings, which require no daily lubrication.



NOTE

Level the saw frame surface prior to service in order to get accurate oil level readings.

Removable Guards and Access Panels

For ease of service access, the following guards and panels are removable:

- Blade guard
- Rear access panel
- Belt guard
- Flange Guard
- Console Access Panel

Replace guards and panels prior to starting the engine.




Fig. 26 — Guards and Panels

Belts and Pulleys

| Belt | Qty | Part Number |
|---------------------------------|-----|-------------|
| Spindle Drive Belt (POWERBAND) | 1 | 520006 |
| Transaxle Drive Belt | 1 | 521005 |
| Engine to Jack shaft Drive Belt | 1 | 521005 |




Fig. 27 — Belt Locations

V-Belt Tension




The ideal V-Belt tension is the lowest tension at which the belt will not slip under peak load conditions. Check V-Belt tension frequently during the first 24-48 hours of run-in operation.



CAUTION

- Over-tensioning shortens belt and bearing life.
- Keep belts clean of foreign material that may cause slippage.
- Make V-Belt inspection a periodic procedure.
- Never dress belts, as this causes premature failure.

Spindle (Blade Shaft) Drive Belt Tension Adjustment

| | | |
|---|---|---|
|  NOTE | <p>When loosening drive belts, lower the saw to reduce stress on the tensioning system, and use gravity to pull the engine forward slightly. When tightening belts, raise the saw, and gravity will aid the process also.</p> | |
|  WARNING |  | <p>NEVER attempt to check or adjust the V-belt tension with the engine running. Severe injury can occur. Keep fingers, hands, hair, and clothing away from all moving parts.</p> |

1. Remove the Upper Belt Guard (see Fig. 26).
2. Loosen the front Engine Mount lock bolts (A, A) only, to allow the engine to slide. **DO NOT** loosen the rear bolts (B, B).
3. With the front bolts loose, the rear Engine Mount bolts (B, B) should have a $\frac{1}{4}$ " space, as shown:




Fig. 28 — Detail of Engine Mount Lock Bolts

4. Loosen the Outer Jam Nut on the Single Point Belt Tension Bolt. Turn the Inner Jam Nut counter-clockwise.
5. Adjust drive belt to desired tension. Do Not over tighten.
6. Tighten Engine Mount Lock Bolts.
7. Tighten the Jam Nuts to prevent the Single-Point Bolt from turning.






Fig. 29 — Spindle Drive Belt Adjustment & Replacement

Replacing the Spindle Drive Belt

1. Remove the Upper and Lower Belt Guards. See Figs. 26 & 29.
2. Loosen the Engine Mount Lock Bolts.
3. Loosen the Single-Point Belt-Tensioning Bolt to allow the belt to slip off the engine sheave.
4. Slide the belt off of the engine sheave and pull the belt down around the Spindle sheave.
5. Slide the belt off the top of the Spindle sheave.
6. Reverse steps 1-5 to install a new belt.

Replacing the Jack Shaft Belt

| | | |
|---|---|---|
|  WARNING |  | <p>NEVER attempt to check or adjust the V-belt tension with the engine running. Severe injury can occur. Keep fingers, hands, hair, and clothing away from all moving parts.</p> |
|---|---|---|

1. Remove the Belt Guards (see Figs. 26 & 29).
2. Loosen the Rotary Tensioner.
3. Remove the Spindle Belt (see above).
4. Remove and replace the Jack Shaft Belt.
5. Replace the Spindle Belt (see above).
6. Adjust the Rotary Tensioner.

Rotary Belt Tensioner

The Rotary Belt Tensioner system uses a 3/4"-headed bolt and either a 15/16" or 1" nut to set belt tension. Adjust Tension Nut to apply tension to the belt. Ridges on the Tensioner Arm gauge the amount of tension applied.

1. Loosen the Tensioner Lock Bolt Head.
2. Adjust the Tensioner Nut for proper belt tension. (This will be achieved at approximately 1-1/2 ridges on the gauge.)
3. Tighten the Tensioner Lock Bolt Head.





Fig. 30 — Jack Shaft Belt and Rotary Belt Tensioner System

Blade Flange Removal/Installation

Correct removal or installation of the Inner Blade Flange or Flange requires a Flange Puller (option Part Number 18503) as shown below.

| | |
|---|--|
|  WARNING | <p>Follow instructions closely to prevent injury from flying Blade Flanges! Because of tapered fit between Blade Flange and Spindle, 5-10 tons of force is needed to release the inner flange. Parts and tools can become dangerous projectiles if instructions are not followed properly.</p> |
|---|--|




Fig. 31 — Using the Flange Puller

Removing the Inner Blade Flange

With the Outer Blade Flange in place, and the Blade Mounting Bolt loosened approximately $\frac{1}{4}$ ":

1. With the three perimeter bolts holding the two Puller Plates together, slide the Horseshoe Plate of the Flange Puller behind the (Shaft) side of the Inner Flange as shown above.
2. Tighten the center Puller bolt to remove the Inner Flange from Spindle.

| | | |
|--|--|--|
| | | <p>Ensure the Outer Flange is in place to prevent the Puller and Inner Flange from flying off when the taper breaks loose, and causing injury!</p> |
|--|--|--|

| | |
|--|--|
| | <p>If the Inner Flange does not readily come free from the tapered Spindle, lightly tap on the central Puller bolt. This should cause the flange to break free from the shaft.</p> |
|--|--|

Installing the Inner Blade Flange

1. Ensure that the tapered portion of the Spindle, and the Inner Spindle are perfectly clean and free of burrs or indentations. Clean and repair as necessary.
2. Ensure that the Drive Key is in place.
3. Slide the Inner Flange onto the tapered portion of the Spindle.

| | |
|--|---|
| | <p><i>Do Not</i> use any lubricant! Lubricant prevents the tapered surfaces of the Flange and Shaft from mating properly.</p> |
|--|---|

4. Install the Outer Blade Flange, Flange Bushing, and Mounting Bolt.
5. Tighten with a 1/2" impact wrench to seat the tapered surfaces of the Inner Flange and Spindle.




Fig. 32 — Installing the Inner Spindle

6. Loosen the Mounting Bolt and remove the Outer Flange and Bushing.
7. Inspect the Inner Flange to ensure the proper seating of the tapered fit.

The Inner Flange should be seated between .030" and 0.0" (flush) to the end of the Spindle.




Fig. 33 — Proper seating of the Inner Flange and Spindle

8. Test to ensure that the Inner Flange does not wobble when rotated. Use a dial indicator on the face of the Flange. *Maximum* tolerance is .003" run-out on the face of the Flange.



NOTE

For Spindle Maintenance/hydraulic oil change see page 58.

Spindle Replacement



NOTE

To assure correct Spindle/Wheel alignment it is recommended that this operation be performed by a Multiquip Authorized Service Center. **DO NOT** unbolt the Spindle Mounting Blocks, as they have been factory installed for correct Spindle/wheel alignment.

1. Remove the Spindle Drive Belts (see Replacing the Spindle Belt, above).
2. Tighten the Engine Mount Lock Bolts to prevent engine movement during step #3.




Fig. 34 — Engine Mount Lock Bolts



DANGER



To prevent the possibility of crush injury, always ensure that the saw is *securely* supported whenever it is lifted for maintenance.

3. Block the wheels then lift the saw to the full up position, and block up the front axle to prevent accidental crush injury.
4. Disconnect the two hoses attached to the Spindle, and plug hoses and Spindle ports to prevent drips and dirt contamination.
5. Support the Spindle to prevent tipping or shifting of weight.
6. Unbolt the Spindle Saddle Clamps using a 3/8" Allen wrench.




Fig. 35 — Spindle Replacement

7. Remove the Spindle.
 - DO NOT unbolt the Spindle Mounting Blocks, as they have been factory-installed for correct Spindle/wheel alignment.
8. Fill the new Spindle with approved hydraulic oil and cap.
9. Perform Steps 1-5 in reverse order.




Fig. 36 — Maintain equal spacing when tightening Saddle Clamps

- Tighten Saddle Clamp bolts equally, maintaining even spacing as you reattach the Saddle Clamps. Torque bolts to 35 ft. lbs. Do Not over-torque. Apply medium strength thread lock, Blue Loctite 242 or equivalent.

Circuit Breakers

Three thermal circuit breakers are located behind the Control Panel access cover.




Fig. 37 — Circuit Breaker location

Under normal circumstance circuit breakers do not require service; they are automatically re-set once an overload condition has been corrected. If one or more breakers are cycling on/off, locate the cause of the electrical overload and repair as required.

Also see the Electrical Schematic on page 61.

Maximum Cut Depth Adjustment

The 3000 Series saws come factory-adjusted for maximum usable cut depth. However, should you desire to adjust the maximum depth:



1. Park the blade-less saw on a flat and level surface.
2. Fully lower the saw onto the Stop Bolts (see Fig. 38).
3. Measure the distance from the Blade Flanges to the surface.
4. Adjust the Stop Bolts in or out until the Blade Flanges have 1/8" to 3/16" ground clearance.
5. Ensure that both bolts are adjusted to the same setting so that the load is evenly distributed.


Lubrication

This saw has six grease fittings. Locations are shown in Figure 38 on the front axle assembly, and one, (not shown) on the Jackshaft assembly.

- Front axle pivot bearings (2)
- Hydraulic lift cylinder end (1)
- Depth cylinder pivot bracket (2)
- Jackshaft pivot (1)

These fittings are easily accessed by raising the saw half way up, and then lifting the rear of the saw until the blade flanges rest on the ground.

| | | |
|--|---|---|
|  WARNING |  | To prevent the possibility of crush injury, ensure that the saw is <i>securely</i> placed on suitable supports before servicing the lubrication points. |
|--|---|---|

| | |
|--|---|
|  DANGER | Grease each fitting every 25 hours of operation using premium grade waterproof E. P. (extreme pressure) grease. |
|--|---|




Fig. 38 — Grease Fittings and Maximum Cut Depth Stops


Engine Maintenance

The Model SP-3035 uses a 35 HP Wisconsin engine. See the engine manual for service details.

- Check air filters daily. Do not clean. Replace as needed. See Caution below.
- Check engine oil level daily.
- Level the saw frame prior to service to get accurate readings.
- Change the engine oil and filter every 50 hours of operation.

Filters

| Filter | Qty | Part Number & Cross Reference |
|-------------------------|-----|-------------------------------|
| Primary Air Filter | 1 | 300000-1 |
| Safety Air Filter | 1 | 300000-2 |
| Engine Oil Filter | 1 | 306004 |
| Hydraulic System Filter | 1 | 306006 |
| Inline Fuel Filter | 1 | 304000 |

| | |
|---|--|
|  DANGER | <p>Safety Air Filters are NOT intended to be used for primary air filtration. When the Primary Filter becomes clogged, replace it immediately - DO NOT run saw using just the Safety filter. DO NOT attempt to clean dirty air filters by any means.</p> |
|---|--|




Fig. 39 — Filters

Raise-Lower System

This saw uses a 12-volt hydraulic pump and cylinder to power the raise-lower system.

- Level the frame prior to service to get accurate readings.
- Check oil level daily.
- Fill the reservoir half full when cold.
- Use 5W-30 premium grade *engine* oil.




Fig. 40 — Raise-Lower System

Control Handle Adjustment

The Control Handle is adjustable to provide the preferred "feel".

1. Using a 1/4" Allen wrench and 9/16" wrench, loosen both pivot bolts until they can be turned by hand. Pivot #1 requires only a 9/16" wrench, as the Allen nut side is welded in place.
2. Tighten pivot #1 until the handle is close to the desired "feel".
3. Tighten pivot #2 until it just starts to increase the force required to move the handle.




Fig. 41 — Control Handle Adjustment

Hydraulic System

The hydraulic system consists of:

| | |
|---|-----------------------------|
| Spindle Assembly (1) | Hydraulic Pump (2) |
| Transaxle Assembly (9) | Hydraulic Manifold (4) |
| Lift Cylinder (5) | Oil Filters (3, 6) |
| Hydraulic Drive and Spindle Oil Reservoir (7) | Lift Cylinder Reservoir (8) |

Routine Maintenance

- Check oil level daily.
- Fill the reservoir to the fill line when cold.
- Level frame prior to service to get an accurate reading.
- Use 5W-30 premium grade *engine* oil.
- Change transaxle oil and filter every 250 hours of operation or annually.
- Change Spindle oil every 250 hours of operation or annually.




Fig. 42 — Hydraulic System Components

Draining & Filling the Hydraulic System

To drain the Transaxle

1. Remove the drain plug from the bottom of the Spindle housing and the bottom of the Transaxle.




Fig. 43 — Transaxle Drain Plug



NOTE

Collect and dispose of the used oil and oil filter in an environmentally friendly manner. Do not drain onto the ground or pour used oil down drains.

2. Remove the old oil filter. See Fig. 43, above.
3. Once drained, reinstall the drain plugs.
4. Pre-fill and install a new oil filter.
5. Refill the Transaxle with hydraulic oil as outlined on page 58



CAUTION

Pre-fill the oil filter with oil prior to installing to prevent hydraulic pump damage.

To drain the Spindle



NOTE

The fully enclosed Spindle eliminates most maintenance. However, if the Spindle ever needs service or repair, contact Multiquip, at the number listed in the inside of the front cover for details.





Fig. 44 — Spindle Assembly

1. Raise the saw 2/3 or more up.
2. Remove the drain plug from the bottom of the Spindle housing.
3. Re-install the drain plug and install a new oil filter.

| | |
|---|--|
|  CAUTION | <p>To prevent damage to the hydraulic pump, pre-fill the new oil filter prior to installation.</p> |
|---|--|

To refill the hydraulic system

1. Ensure the saw is fully lowered if it had been raised.
2. Add hydraulic oil to the Drive & Spindle System Reservoir.
 - Oil will need to be added several times.
3. Jack the unit up so the drive wheels are off the ground, then run the engine for a couple minutes to cycle oil throughout the system.
4. Add more oil as required.
5. Inspect for leaks after service.

Tips

- Remove the oil reservoir cap to speed draining.
- Before installing a new filter, fill the reservoir and let it drain down to the filter manifold. Once new oil reaches the manifold, install the new pre-filled filter.
- To help speed up the refilling process, raise the saw half-way up and lift the rear of the saw until the Blade Flanges touch the ground.
- After filling the system, jack the saw up so the drive wheels are off the ground. Start the saw, and move the joystick half way into FORWARD, to purge air out of the system.

Drive Wheel Alignment

Below is the suggested technique for aligning the wheels. Distance X is the same on either side; the Front Axle and Spindle must be at right angles to the frame edge. Distance A is 3/16" (.187") longer on the right side, so that the saw steers slightly left. Users may wish to alter the alignment to fit a particular application.




Fig. 45 — Drive Wheel Alignment

The drive wheels are aligned by adjusting the entire rear drive assembly.

1. Raise the saw halfway, then lift the rear of the saw until flanges touch the ground. Use suitable supports to prevent tipping or shifting of weight.
2. Loosen the adjustment-side attachment bolts until washers spin freely.
3. Loosen pivot-side bolts enough to move the adjustment-side wheel in the appropriate direction to achieve the desired alignment distance.
4. Tighten the Transaxle Attachment Bolts when the appropriate alignment distance is set.




Fig. 46 — Drive Wheel Alignment Bolt Locations

Positraction Adjustment




Fig. 47 — Positraction Adjustment Bolt Locations

1. Lift Saw 4" to 6" and tilt forward to place spindle flanges on ground. When flanges are on the ground, depress Raise Button to raise the rear of the saw to full height. Use suitable stands to hold rear of saw up.
2. Disengage Positraction Lever fully.
3. Loosen Positraction clamping plate bolts enough to adjust Positraction assembly.
4. Insert 1/8" flat spacer between Positraction drive hub and rear wheel on both sides. Use a finger-type clamp to compress the drive hub and the rear wheel, insert spacers between contact points of wheel and hub. Tighten clamp until rear wheel compresses slightly.
5. Tighten Positraction clamping bolts to secure Positraction assembly. Remove clamps and spacer.
6. Remove supports. Grasp the handlebars securely and depress the "Lower" button until the rear of the saw has lowered sufficiently to safely lower the rear wheels to the ground.

EXPLANATION OF CODE IN REMARKS COLUMN

The following section explains the different symbols and remarks used in the Parts section of this manual. Use the help numbers found on the back page of the manual if there are any questions.

The contents and part numbers listed in the parts section are subject to change **without notice**. Multiquip does not guarantee the availability of the parts listed.

Sample Parts List:

| NO. | PART NO. | PART NAME | QTY. | REMARKS |
|-----|----------|---------------------|--------|---------------------|
| 1 | 12345 | BOLT..... | 1..... | INCLUDES ITEMS W/# |
| 2# | | WASHER, 1/4 IN..... | | NOT SOLD SEPARATELY |
| 2# | 12347 | WASHER, 3/8 IN..... | 1.... | MQ-45T ONLY |
| 3 | 12348 | HOSE..... | | A/R... MAKE LOCALLY |
| 4 | 12349 | BEARING..... | 1.... | SN2345B AND ABOVE |

NO. Column

Unique Symbols - All items with same unique symbol (\$, #, +, %, or >) in the number column belong to the same assembly or kit, which is indicated by a note in the "Remarks" column.

Duplicate Item Numbers- Duplicate numbers indicate multiple part numbers are in effect for the same general item, such as different size saw blade guards in use or a part that has been updated on newer versions of the same machine.



NOTE

When ordering a part that has more than one item number listed, check the remarks column for help in determining the proper part to order

PART NO. Column

Numbers Used - Part numbers can be indicated by a number, a blank entry, or TBD.

TBD (To Be Determined) is generally used to show a part that has not been assigned a formal part number at time of publication.

A blank entry generally indicates that the item is not sold separately or is not sold by Multiquip. Other entries will be clarified in the "Remarks" Column.

QTY. Column

Numbers Used - Item quantity can be indicated by a number, a blank entry, or A/R.

A/R (As Required) is generally used for hoses or other parts that are sold in bulk and cut to length.

A blank entry generally indicates that the item is not sold separately. Other entries will be clarified in the "Remarks" Column.

REMARKS Column

Some of the most common notes found in the "Remarks" Column are listed below. Other additional notes needed to describe the item can also be shown.

Assembly/Kit - All items on the parts list with the same unique symbol will be included when this item is purchased.

Indicated by:
"INCLUDES ITEMS W/(unique symbol)"

Serial Number Break - Used to list an effective serial number range where a particular part is used.

Indicated by:
"S/N XXXXX AND BELOW"
"S/N XXXX AND ABOVE"
"S/N XXXX TO S/N XXX"

Specific Model Number Use - Indicates that the part is used only with the specific model number or model number variant listed. It can also be used to show a part is NOT used on a specific model or model number variant.

Indicated by:
"XXXXX ONLY"
"NOT USED ON XXXX"

"Make/Obtain Locally" - Indicates that the part can be purchased at any hardware shop or made out of available items. Examples include battery cables, shims, and certain washers and nuts.

"Not Sold Separately" - Indicates that an item cannot be purchased as a separate item and is either part of an assembly/kit that can be purchased, or is not available for sale through Multiquip.

SUGGESTED SPARE PARTS

MQ SP-3035 CONCRETE SAW WITH WISCONSIN 35
HP AIR-COOLED DIESEL ENGINE

1 to 3 Units

| Qty. | P/N | Description |
|---------|----------|--|
| 1 | 300000-1 | FILTER, AIR, ELEMENT, PRIMARY |
| 1 | 300000-2 | FILTER, AIR ELEMENT, SAFELY |
| 1 | 306004 | FILTER, OIL, WISCONSIN 35 HP |
| 1 | 306006 | FILTER, TRANSAXLE |
| 1 | 304000 | FILTER, FUEL, WISCONSIN 35 HP |
| 1 | 520006 | V-BELT, 6 3VX425 (GOODYEAR) |
| 1 | 521005 | V-BELT, AX-31 (GOODYEAR) |
| 1 | 15503 | COMFORT GRIP KNOB |
| 1 | H9406 | NIGHT LIGHT BULB |
| 1 | 400000 | LIFT PUMP SOLENOID |
| 1 | 362002 | TUBE, WATER, RH SIDE |
| 1 | 362003 | TUBE, WATER, LH SIDE |
| 1 | 200019 | FLAP, MUD, BLADEGUARD |
| 1 | 406000 | SWITCH, ROCKER |
| 2 | 180000 | BLADE COLLAR, INSIDE |
| | 180001 | BLADE COLLAR ASSY, OUTER |
| 2 | 980705 | PIN, DOWEL 3/8 X 1-1/4" |
| 2 | 582012 | BUSHING, QUICK DISCONNECT |
| SPINDLE | | |
| 1 | 915315 | SCREW, HHC 5/8-11 X 3 GRD8 |
| 1 | 915316 | SCREW, HHC 5/8 -11 X 3 LH GR8 |
| 1 | 25832 | ROPE ASSY, FRONT POINTER |
| 1 | 35131 | MOUNTING HORN, AXLE |
| 1 | 25839 | FRONT WHEEL ASSY |
| 2 | 500011 | REAR WHEEL |
| 2 | 528038 | REAR WHEEL KEYLESS BUSHING |
| 1 | 29509 | CAP, FUEL TANK 2.25 DIA, ONE WAY VALVE |




NOTE

Part numbers on this Suggested Spare Parts List may supercede/replace the P/N's shown in the test pages of this manual.

COMPONENT DRAWINGS

Nameplate and Decals Assy.

The Multiquip SP-3035 Saw is equipped with a number of operation and safety decals. Should any of these decals become unreadable, replacements can be obtained from your dealer.






Nameplate and Decals Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|-----------|----------------|-------------------------------------|-------------|----------------|
| 1 | 25250-001 | DECAL, WARNING, KEEP FEET CLEAR | 2 | |
| 2 | 606004 | DECAL, BLADE GUARD REMOVAL | 2 | |
| 3 | 25782 | DECAL, MQ DIAMOND LOGO | 4 | |
| 4 | 21302 | DECAL, WARNING, INSTALL BLADE GUARD | 2 | |
| 5 | 25785 | DECAL, SP3 LOGO | 3 | |
| 6 | 13118 | DECAL, POWDER COATED | 1 | |
| 7 | 35137 | DECAL, WARNING, READ MANUAL | 1 | |
| 8 | 1997 | DECAL, NAMEPLATE | 1 | |
| 9 | M600021 | DECAL, UNLEADED FUEL ONLY | 1 | |
| 10 | 22122-001 | DECAL, WARNING, SERIOUS INJURY | 1 | |
| 11 | 25249-001 | DECAL, WARNING, KEEP HANDS CLEAR | 2 | |
| 12 | 23330-001 | DECAL, CAUTION, DRIVE BELT | 1 | |
| 13 | 25491 | DECAL, ROTATION, CW | 1 | |
| 14 | 20525 | DECAL, WARNING, PROPOSITION 65 | 1 | |
| 15 | 604001 | DECAL, WARNING, INSTALL BELT GUARD | 1 | |
| 16 | 25678 | DECAL, ROTATION, CCW | 1 | |

MQ SP-3035 Concrete Saw — Deck/Gauge Panel Assy.

Deck/Gauge Panel Assy.




MQ SP-3035 Concrete Saw — Deck/Gauge Panel Assy.

Deck/Gauge Panel Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|-----------|----------------|------------------|-------------|----------------|
| 1 | M600020 | GAUGE PANEL | 1 | |
| 2 | M600019 | DECK PANEL | 1 | |

Console/Sheet Metal Assy.




MQ SP-3035 Concrete Saw — Console/Sheet Metal Assy.

Console/Sheet Metal Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|-------------------------------------|-------------|--------------------|
| 1# | 0166 | SCREW, HHC 3/8-16 X 7/8 | 3 | |
| 2# | 933242 | WASHER, FLAT SAE 3/8 GRD 9 YZ | 3 | |
| 3# | 204007 | BELT GUARD | 1 | |
| 8 | 25796 | CONSOLE, RED | 1 | |
| 18 | 0655 | SCREW, HHC 5/16-18 X 3/4 | 6 | |
| 19 | 25865 | HARNESS, LIGHT KIT, SOCKET | 1 | |
| 22 | 25805 | PANEL, CONSOLE COVER, RED | 1 | |
| 25 | 3214 | SCREW, HHC 1/2-13 X 1-1/4 | 6 | |
| 26 | 933244 | WASHER, FLAT SAE 1/2 GRD 9 YZ | 6 | |
| 28# | 15503 | KNOB, COMFORT GRIP STAR, 3/8-16 X 1 | 1 | |
| 29# | 584011 | WRENCH, 15/16" BLADE CLOSED END | 1 | |
| 30 | 923114 | SCREW, SHC 8-32 X 1/2 | 2 | |
| 31 | 35180 | BELT GUARD ASSY | 1 | INCLUDES ITEMS W/# |
| 32 | 13287 | NUT, NYLOC 8-32 | 2 | |


Access Panel Assy.



Access Panel Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|--------------------------------------|-------------|--------------------|
| 1# | 25795 | PANEL, REAR CONSOLE, RED | 1 | |
| 2# | 29057 | DOCUMENT BOX, CP90007-07 | 1 | |
| 3# | 560020 | LATCH, REAR SAW ACCESS PANEL | 2 | |
| 4# | 577002 | WEATHER STRIP, REAR SAW ACCESS PANEL | 1.75 FT. | |
| 5# | 12287 | SCREW, THP 1/4-20 X 3/4" SS | 4 | |
| 6# | 10024 | NUT, NYLOCK 1/4-20 | 4 | |
| 7# | 10930 | WASHER, FENDER, 1/4 X 1-1/4" | 4 | |
| 8 | 25794 | PANEL ASSY., REAR CONSOLE, RED | 1..... | INCLUDES ITEMS W/# |


Fuel Tank Assy.



Fuel Tank Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|---|-------------|--------------------|
| 1# | 1400003 | TANK, FUEL | 1 | |
| 2# | 29509 | CAP, FUEL TANK 2.25" DIA. ONE WAY VALVE | 1 | |
| 3# | 19633 | BUSHING, RUBBER FUEL DAPCO 10672 | 1 | |
| 4# | 446005 | VALVE, FUEL ON/OFF 1/4" | 1 | |
| 5# | 19473 | CLAMP, HOSE WORM #2 | 4 | |
| 6# | 35022 | CLAMP, LOOP CUSHIONED #8 | 1 | |
| 7# | 35059 | HOSE, FUEL .250 ID, 12" | 1 | |
| 8# | 2295 | SCREW, HHC 1/4-20 X 7/8" | 1 | |
| 9# | 304000 | FILTER, FUEL, WISCONSIN | 1 | |
| 10# | 35060 | HOSE, FUEL .250 ID, 11" | 1 | |
| 11# | 370626 | FITTING, 45° 4BARB-1/8" MP | 1 | |
| 12# | 367216 | FITTING, 90°-1/8" FP-1/8" MP | 1 | |
| 13 | 25831 | FUEL TANK ASSY | 1 | INCLUDES ITEMS W/# |
| 14 | 25801 | MOUNT, FUEL TANK | 1 | |
| 15 | 933242 | WASHER, FLAT SAE 3/8" GD9 | 4 | |
| 16 | 4196 | SCREW, SHC 8-32 X 1/2" | 4 | |

F-N-R Control Handle Assy.




MQ SP-3035 Concrete Saw — F-N-R Control Handle Assy.

F-N-R Control Handle Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|---------------------------------|-------------|--------------------|
| 1 | 560030 | F-N-R CONTROL HANDLE ASSY. | 1 | INCLUDES ITEMS W/# |
| 2# | 560028-6 | SCREW, #6-32 X 3/8 | 5 | |
| 3# | 5600028-8 | WASHER, FLAT #4 NYLON | 5 | |
| 4# | 560028-4 | RUBBER BOOT | 2 | |
| 5# | 560028-3 | PLATE, SIDE SWITCH | 1 | |
| 6# | 560028-5 | SWITCH ASSEMBLY | 2 | |
| 7# | 560028-1 | HANDLE HOUSING | 1 | |
| 8# | 60118 | WIRE, F-N-R | 1 | |
| 9# | 925381 | SCREW, SET 1/4-20 X 3/8 | 1 | |
| 10# | 560028-2 | PLATE, FRONT SWITCH | 1 | |
| 11 | 35176 | F-N-R CONTROL ASSY. | 1 | INCLUDES ITEMS W/% |
| 12% | 25627 | F-N-R CONTROL | 1 | |
| 13% | 405070 | SEAL, WEATHERPACK | 4 | |
| 14% | 405046 | CONNECTOR, MALE | 1 | |
| 15% | 12223 | TERMINAL WEATHERPACK | 4 | |
| 16% | 6904 | NUT, HEX FINISH 1/4-28 ZINC | 4 | |
| 17% | 580001 | ROD END, 1/4-20 FEMALE RH | 2 | |
| 18% | 440006 | CABLE, CONTROL 40" X 2" STROKE | 1 | |
| 19% | 120077 | MOUNT TRANSAXLE CTRL. CABLE | 1 | |
| 20% | 565006 | SPRING, CTRL. CABLE TENSIONING | 1 | |
| 21% | 915003 | SCREW, HHC 1/4-20 X 3/4 GRD. 8 | 1 | |
| 22% | 584044 | RETAINER, FNR CABLE SPRING | 1 | |
| 23% | 2295 | SCREW, HHC 1/4-20 X 7/8 | 1 | |
| 24% | 440005 | PLATE, F-N-R PINTLE CONTROL | 1 | |
| 25% | 933240 | WASHER, FLAT SAE 1/4" GRD. 9 | 1 | |


Joystick Mounting Assy.



Joystick Mounting Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|---------------------------------|-------------|--------------------|
| 1# | 0161D | NUT, HEX FINISH 5/16-18 | 2 | |
| 2# | 10019 | NUT, FYLOC #10-32 | 1 | |
| 3# | 1579 | SCREW. JJC 1/4-20 X .5 | 1 | |
| 4# | 2203 | WASHER, FLAT, #10 | 4 | |
| 5# | 405053 | CORD GRIP, SAW FNR CONTROL | 1 | |
| 6# | 442005-6 | BOOT, FNR CONTROL HANDLE | 1 | |
| 7# | 442006-3 | SPACER, F-N-R | 1 | |
| 8# | 442011 | BELLCRANK, SAW F-N-R | 1 | |
| 9# | 442012 | PLATE, NEUTRAL DETENT | 1 | |
| 10# | 442013 | F-N-R MOUNTING PLATE | 1 | |
| 11# | 442021 | CONTROL LEVER | 1 | |
| 12# | 442022 | SPACER, F-N-R DELRIN | 1 | |
| 13# | 460018 | CAM ROLLER, SAW FNR CONTROL | 1 | |
| 14# | 565005 | EXTENSION SPRING F-N-R CONTROL | 1 | |
| 15# | 584021 | DENTENT BALL, SAW FNR CONTROL | 1 | |
| 16# | 584023 | PIN, LONG SPRING HANGER | 1 | |
| 17# | 584024 | PIN, SHORT SPRING HANGER | 1 | |
| 18# | 926348 | SCREW, SHOULDER 3/8-16 X 3/4 | 1 | |
| 19# | 933015 | FRICTION DISC, SAW F-N-R | 1 | |
| 20# | 933073 | 1/2 X 1-1/4 BELLEVILLE WASHER | 3 | |
| 21# | 933225 | WASHER, FENDER 1/2 X 1-1/2 ZINC | 1 | |
| 22# | 933240 | WASHER, FLAT 1/4 SAE | 1 | |
| 23# | 933242 | WASHER, FLAT 3/8 SAE | 1 | |
| 24# | 938062 | LOCKNUT 3/8-16 YZ | 2 | |
| 25# | 973735 | SCREW, BHSC 10-24X1-SS | 4 | |
| 26 | 35122 | F-N-R MOUNTING ASSY..... | 1 | INCLUDES ITEMS W/# |


Lift Pump Circuit Assy.



Lift Pump Circuit Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|---------------------------------|-------------|---------------|
| 2 | 340011 | PUMP, LIFT | 1 | |
| 3 | 169003 | PIN, CYLINDER | 2 | |
| 4 | 447007 | CYLINDER, LIFT | 1 | |
| 5 | 21159 | FITTING, 45 4MJ-4MO | 1 | |
| 6 | 368817 | FITTING, 90 4MJ-4MO | 1 | |
| 7 | 35149 | FITTING, ORIFICE 4MJ-4MO | 1 | |
| 8 | 366640 | FITTING, 90 4MJ-4FJ | 1 | |
| 9 | 35157 | FITTING, TEE 4MO-4MJ | 1 | |
| 10 | 35156 | HOSE ASM, 11.3" | 1 | |
| 11 | 35250 | HOSE ASM, 10.7" | 1 | |
| 12 | 366437 | FITTING, BULKHEAD #4 JIC | 1 | |
| 13 | 35248 | HOSE ASM 9.1" | 1 | |
| 14 | 570050 | CLAMP ASM #4 SINGLE HOSE | 1 | |
| 15 | 35057 | HOSE ASM 28.7" | 2 | |
| 16 | 0655 | SCREW, HHC 5/16-18 X 3/4 | 2 | |
| 17 | 933241 | WASHER, FLAT SAE 5/16 GRD 9 YZ | 2 | |
| 18 | 933240 | WASHER, FLAT SAE 1/4 GRD 9 YZ | 2 | |
| 19 | 20909 | SCREW, HHC 1/4-20 X 2 | 2 | |
| 20 | 0949 | NUT, HEX FINISH 1/4-20 X 3/8 NP | 2 | |
| 23 | 480003 | SEAL, OIL CR# 9815 | 4 | |
| 24 | 2621 | FITTING, GREASE ZERK STR 1/4-28 | 1 | |
| 25 | 446009 | SOLENOID VALVE ASM, SAW LIFT | 1 | |
| 26 | 400000 | SOLENOID, 12VDC | 1 | |
| 27 | 923000 | SCREW, SHC 1/4-20 X 3/8 NP | 2 | |
| 28 | 933076 | WASHER, FLAT SAE #12 ZINC | 2 | |


Water System Assy.



Water System Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|--|-------------|---------------|
| 1 | 446004 | VALVE, BALL, 1/2 BRASS | 1 | |
| 2 | 35047 | HOSE ASM, 95.1" #8LP | 1 | |
| 3 | 35052 | HOSE, 1/2 ID PUSHLOCK 250 PSI, 8" | 1 | |
| 4 | 25059 | FITTING, BRASS 8 PUSH-ON 1/2 MP | 1 | |
| 5 | 25931 | FITTING, 90 8 BARB - 1/2 MP | 2 | |
| 6 | 26496 | FITTING, 90 1/2 MP - 1/2 FP | 1 | |
| 7 | 25827 | FITTING, BRASS (F) 3/4 GHT SWIVEL 1/2 MNPT | 1 | |


Depth Indicator Assy.



Depth Indicator Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|--|-------------|---------------|
| 1 | 125032 | DEPTH INDICATOR U-BRACKET | 1 | |
| 2 | 110031 | POINTER, DEPTH | 1 | |
| 3 | 560025 | KNOB, COMFORT GRIP | 1 | |
| 4 | 460019 | FLANGE BEARING, .25ID | 1 | |
| 5 | 973752 | SCREW, BHSC, 1/4-20 X 5/8 SS | 2 | |
| 6 | 584025 | STUD, 1/4-20 X 1-3/4 | 1 | |
| 7 | 10024 | NUT, NYLOC 1/4-20 | 2 | |
| 8 | 926149 | SCREW, SHDLR 1/4D X 5/16L, 10-24 SCKT HD | 2 | |
| 9 | 1618 | NUT, NYLOC 10-24 | 2 | |
| 10 | 933240 | WASHER, FLAT SAE 1/4 GRD 9 YZ | 4 | |
| 11 | 540011 | PULLEY, CABLE 1-1/4" OD X .25 SHAFT | 4 | |
| 12 | 583059 | SHIM, .020" THICK, .251" ID, .375" OD | 9 | |
| 13 | 440012 | DEPTH INDICATOR CABLE | 1 | |
| 14 | 120243 | PIVOT TAB | 1 | |
| 15 | 0131 A | SCREW, HHC 1/4-20 X 3/4 | 1 | |
| 16 | 1579 | SCREW, HHC 1/4-20 X 1/2 | 1 | |
| 17 | 565004 | SPRING, EXTENSION | 1 | |
| 18 | 160013 | AXLE, INDICATOR SHEAVE | 1 | |
| 19 | 923116 | SCREW, SHC 8-32 X 3/4 | 2 | |
| 20 | 13287 | NUT, NYLOC | 2 | |


Handle and Light Assy.



Handle and Light Assy.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|--------------------------------|-------------|----------------|
| 1 | 12387 | NUT, NYLOCK 8X32 | 2 | |
| 2 | 120206 | LIGHT BAR, CONCRETE SAW | 1 | |
| 3 | 405001 | CONNECTOR, PLUG, 4 PIN FEMALE | 1 | |
| 4 | 0161 C | WASHER, LOCK 5/16" | 1 | |
| 5 | 0161 D | NUT, 5/16-18 | 1 | |
| 6 | 560023-1 | HANDLE BAR, CONCRETE SAW | 2 | |
| 7 | 560024 | KNOB, HANDLEBAR | 2 | |
| 8 | 923199 | SCREW, SHC 8-32 X 1-1/4 | 2 | |
| 9 | 574002 | CAM CLEAT | 1 | |
| 10 | 35359 | TERMINAL, FEM-SMALL 16-18 GA | 2 | |
| 11 | 405002 | CORD, LIGHT-EXTENDABLE | 1 | |
| 12 | 2532 | LIGHT ASSY., RECTANGULAR COMP. | 1 | |
| 13 | 560017 | GRIP HANDLE BAR | 2 | |
| 14 | 0655 | SCREW, HHC 5/16-18" X 3/4 | 1 | |
| 15 | 933241 | WASHER, FLAT SAE 5/16 GRD 9 YZ | 2 | |
| 16 | 120244 | MOUNT CAM | 1 | |

Front/Rear Pointer Assy.




MQ SP-3035 Concrete Saw — Front/Rear Pointer Assy.

Front/Rear Pointer Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|-------------------------------------|-------------|--------------------|
| 1# | 120045 | RIGHT SIDE POINTER | 1 | |
| 2# | 120046 | LEFT SIDE POINTER | 1 | |
| 3# | 25832 | ROPE ASSY., FRONT POINTER | 1 | |
| 4# | 110044 | POINTER, FRONT 17-1/4" | 1 | |
| 5# | 15503 | KNOB, COMFORT GRIP STAR, 3/8-16 X 1 | 1 | |
| 6# | 500005 | WHEEL, POINTER 6 X 1 | 1 | |
| 7# | 160004 | AXLE, POINTER WHEEL | 1 | |
| 8# | 582008 | BUSHING, FLANGE, 1 OD X 3/4 ID | 4 | |
| 9# | 966166 | PIN, CLEVIS 3/4 X 2 | 2 | |
| 10# | 965105 | PIN, COTTER 5/32 X 1-1/2 PLTD | 2 | |
| 11# | 933241 | WASHER, FLAT SAE 5/16 GRD 9 YZ | 2 | |
| 12# | 0202 | SCREW, HHC 5/16-18 X 1 ZINC | 2 | |
| 13# | 926006 | SCREW, SQHS, CP 1/4-20 X 1/2 | 2 | |
| 14# | 1493 | SCREW, HHC 3/8-16 X 3.25 | 1 | |
| 15# | 10133 | NUT, NYLOC 3/8-16 | 1 | |
| 16# | 1456 | NUT, HEX FINISH 3/8-16 | 2 | |
| 17# | 3233 | WASHER, FENDER, 1.5OD X 3/8ID | 2 | |
| 18# | 933244 | WASHER, FLAT SAE 1/2 " GRD 9 YZ | 2 | |
| 19 | M10005 | FRONT POINTER ASSY..... | 1 | INCLUDES ITEMS W/# |
| 20 | 110020 | POINTER, REAR | 1 | |
| 21 | 0205 | SCREW, HHC 3/8-16 X 1 ZINC | 2 | |


Gauges and Controls Assy.



Gauges and Controls Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|-------------------------------------|-------------|-----------------------------|
| 1 | 15171 | CABLE PULL | 1 | |
| 2 | 446004 | VALVE, WATER FLOW CONTROL | 1 | |
| 3 | 25627 | F-N-R CONTROL ASSY. | 1 | |
| 4 | 560025 | KNOB, COMFORT GRIP | 1 | |
| 5 | 574002 | CAM CLEAT | 1 | |
| 6 | 15481 | CABLE, CHOKE 45" | 1 | |
| 7 | 120210 | MOUNT THROTTLE CABLE | 1 | |
| 8 | TBD | WASHER | 1 | |
| 9 | 25634 | BULK HEAD ADAPTER | 2 | |
| 10 | TBD | NUT | 2 | |
| 11 | TBD | NUT | 2 | |
| 12 | 15171 | CABLE, PULL THROTTLE | 1 | |
| 13 | 584028 | PIVOT END, CABLE | 1 | |
| 14 | 926327 | SCREW SHDLR | 1 | |
| 15 | 25634 | BULK HEAD ADAPTOR | 1 | |
| 16 | 933242 | WASHER FLAT SAE | 5 | |
| 17 | 5283 | NUT, NYLOC 5/15 | 1 | |
| 18 | 35174 | POSITRACTION UPPER LEVER ASSY. | 1 |SEE POSITRACTION ASSY. |
| 19 | 406001 | SWITCH, IGNITION | 1 | |
| 20 | 423000 | VOLT METER | 1 | |
| 21 | 421000 | TACHOMETER | 1 | |
| 22 | 406000 | SWITCH, ROCKER | 2 | |
| 23 | 35125 | HARNES, WIRING | 1 | |
| 24 | 406012 | MOUNTING BAR, CIRCUIT BREAKER | 1 | |
| 25 | 933241 | WASHER, FLAT SAE 5/16 GRD 9 YZ | 2 | |
| 26 | 923201 | SCREW, SHC 1/4-20 X 1/2 | 2 | |
| 27 | 406019 | CIRCUIT BREAKER, 10 AMP | 2 | |
| 28 | 25935 | NUT, HEX 10-32 W/STAR WASHER | 2 | |


Front Axle Assy.



Front Axle Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|----------------------------|-------------|--------------------|
| 8 | 913161 | SCREW, HHC 7/16-14 X 2 | 4 | |
| 9 | 933243 | WASHER, FLAT SAE 7/16 | 8 | |
| 10 | 100005 | BEARING BACKING PLATE | 2 | |
| 11 | 460006 | BEARING, FLANGED, 1" | 2 | |
| 12 | 16677 | NUT, LOCK NUT, NYLOC 7/16 | 4 | |
| 13 | 2621 | FITTING, GREASE ZERK STR | 2 | |
| 14 | 926064 | SCREW, SQHS, CP | 2 | |
| 15 | 16010-1 | FRONT AXLE | 1 | |
| 16 | 25839 | FRONT WHEEL ASSEMBLY | 2..... | INCLUDES ITEMS W/# |
| 17# | 485002 | SEAL | 2 | |
| 18# | 500003 | WHEEL, FRONT 3" X 6" | 2 | |
| 19# | 460002 | BEARING | 4 | |
| 20# | M508006 | SPACER | 2 | |
| 21# | 576003 | SNAP RING | 2 | |
| 22 | 933246 | WASHER, FLAT SAE 5/8 | 2 | |
| 23 | 06505-008 | SCREW, HHC 5/8-11 X 1.00 | 2 | |
| 24 | 508005 | COVER, WHEEL, FRONT | 2 | |
| 25 | 1579 | SCREW, HHC 1/4-20 X 1/2 | 6 | |


Depth Stop Assy.



Depth Stop Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|-------------------------------|-------------|---------------|
| 1 | 35120 | DEPTH STOP LEAD SCREW | 1 | |
| 2 | 933244 | WASHER, FLAT SAE 1/2 | 3 | |
| 3 | 565002 | SPRING, COMPRESSION, 7/8 | 1 | |
| 4 | 582009 | COLLAR, SET .50 ID | 1 | |
| 5 | 442014 | DEPTH STOP LINKAGE | 1 | |
| 6 | 19974 | PIN, CLEVIS 1/2 X 1.25 EFFECT | 1 | |
| 7 | 965103 | PIN, COTTER 5/32 X 1 PLTD | 1 | |


Platform Assy.



Platform Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|------------------------------------|-------------|---------------|
| 1 | 25807 | PLATFORM | 1 | |
| 3 | 924287 | SCREW, FHSC, 3/8-16 X 1-1/4,NP | 6 | |
| 4 | 120038 | CLIP, MOUNT,BLADEGUARD | 1 | |
| 5 | 120040 | SPACER, BLADEGUARD CLIP, .25 THICK | 2 | |
| 6 | 3214 | SCREW, HHC 1/2-13 X 1 1/4 | 3 | |
| 7 | 933244 | WASHER, FLAT SAE 1/2 GRD 9 YZ | 3 | |
| 8 | 583092 | WASHER, LOWER BELT PROTECTOR | 1 | |
| 9 | 25837 | GUARD, LOWER BELT PROTECTOR | 1 | |
| 10 | 25820 | WASHER, STRAP LOWER BELT PROTECTOR | 1 | |
| 11 | 120092 | CLIP, RH BLADE GUARD MOUNT | 1 | |
| 12 | M200000 | GUARD, BLADE COLLAR - SLATE GREY | 1 | |
| 13 | 5283 | NUT, NYLOC 5/16-18 | 1 | |
| 14 | 926327 | SCREW, SHSHLDR, 5/16-18X1/2 | 1 | |
| 15 | 448002 | LEVER, CAM | 1 | |
| 16 | 933242 | WASHER, FLAT SAE 3/8 GRD 9 YZ | 3 | |


Drive Assy.



Drive Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|--|-------------|---------------------|
| 1 | 263002 | TRANSAXLE ASSY. | 1 | INCLUDES ITEMS W/% |
| 2 | 35325 | WHEEL, POLY-11X3 | 2 | REPLACES P/N 500011 |
| 3 | 582038 | BUSHING, 1.0" TRANSTORQUE KEYLESS | 2 | |
| 4 | 206005 | SKID PLATE, TRANSAXLE | 1 | |
| 5 | 35190 | FAN ASSY. | 1 | INCLUDES ITEMS W/# |
| 6 | 120078 | BACKING PLATE, SAW TRANSAXLE | 2 | |
| 7 | 540033 | PULLEY, 4.13 X A X 18 TOOTH SPLINE | 1 | |
| 8 | 06500-020 | SCREW, HHC 5/16-18X2-1/2 | 2 | |
| 9 | 933241 | WASHER, FLAT SAE 5/16 GRD 9 YZ | 4 | |
| 10 | 5283 | NUT, NYLOC 5/16-18 | 2 | |
| 11# | 933242 | WASHER, FLAT SAE 3/8 GRD 9 YZ | 8 | |
| 12 | 1493 | SCREW, HHC 3/8-16X3.25 | 8 | |
| 13% | BDU-10L-122 | PUMP MOTOR SUNSTRAND | 1 | |
| 14 | 25495 | SCREW, HHC 5/16-18X4-1/2 | 3 | |
| 15 | 0202 | SCREW, HHC 5/16-18X1 ZINC | 6 | |
| 16% | 35151 | MOUNTING HORN, AXLE | 2 | |
| 17# | 933201 | WASHER, FENDER 3/16X3/4 ZINC | 1 | |
| 18# | 933072 | WASHER, FLAT SAE #8 ZINC | 1 | |
| 19# | 923118 | SCREW, SHC 8-32X1 NP | 1 | |
| 20# | 583064 | STAND-OFF, 1.00 HEX X 1.483 | 1 | |
| 21# | 384001 | FAN, 5-BLADE | 1 | |
| 22 | 25623 | CIRCLIP, RETAINER | 1 | |
| 23 | 35019 | HOSE, 1/2 ID PUSHLOCK 250 PSI, 6" | 1 | |
| 24 | 370192 | FITTING, 45 8BEAD SHORT-6MO | 3 | |
| 25 | 370162-1 | FITTING, 90 8BARB - 6MO | 2 | |
| 26 | 368699 | FITTING, PLUG 6MO HEX SKT HD | 1 | |
| 27 | 35054 | HOSE, 1/2 ID PUSHLOCK 250 PSI, 22.25" | 1 | |
| 28 | 25976 | HOSE, 1/2 ID PUSHLOCK 250 PSI, 18.5" | 1 | |
| 29 | 35226 | FITTING, 90 8 BEADED HOSE X 10MO | 1 | |
| 30 | 35050 | HOSE ASM, 8.25" #6LP w/35253/370674 | 1 | |
| 31 | 35051 | HOSE ASM, 32.85" #6LP w/ 368103 | 1 | |
| 32 | 366692 | FITTING, TEE RUN 6MJ - 6MJ - 6FJ | 1 | |
| 33 | 570053 | CLAMP ASM, WELD, #6 DOUBLE HOSE | 1 | |
| 34 | 35049 | HOSE ASM, 22.75" #6LP w/ 370674/370674 | 1 | |
| 35 | 35048 | HOSE ASM, 54.9" #6LP w/ 370674 | 1 | |
| 36 | 120260 | PLATE, HYDRAULIC OIL FILTER ADAPTER | 1 | |
| 37 | 25617 | FILTER HEAD, TRANSAXLE | 1 | |
| 38 | 306006 | FILTER, TRANSAXLE | 1 | |
| 39 | 144003 | RESERVOIR, HYDRAULIC OIL | 1 | |
| 40 | 367470 | FITTING, STR 4MJ - 6MO | 1 | |
| 41 | 923200 | SCREW, SHC 1/4-20 X 3/8 NP | 2 | |
| 42 | 933076 | WASHER, FLAT SAE #12 ZINC | 4 | |
| 43 | 923201 | SCREW, SHC 1/4-20 x 1/2 | 4 | |
| 44 | 11780 | FITTING, 45 6MJ-6MO | 1 | |

Bladeshaft and Mounting Assy.




MQ SP-3035 Concrete Saw — Bladeshaft and Mounting Assy.

Bladeshaft and Mounting Assy.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|---|-------------|--------------------|
| 1 | 35270 | BLADESHAFT AND MOUNTING GROUP | 1..... | INCLUDES ITEMS W/# |
| 2# | 25840 | BLADESHAFT ASSY. W/TACH P/U..... | 1..... | INCLUDES ITEMS W/% |
| 4# | 25842 | MOUNTING BLOCK, BLADESHAFT | 1 | |
| 5# | 120220 | MOUNTING BLOCK, BLADESHAFT W/PIN | 1 | |
| 6# | 120221 | SADDLE CLAMP 1.50X4.00 BLADESHAFT | 2 | |
| 7# | 923357 | SCREW, SHC 7/16-14 X 1-1/4, NP | 4 | |
| 8# | 16530 | SCREW, HHC 7/16-14 X 1 | 2 | |
| 9# | 933243 | WASHER, FLAT SAE 7/16 GRD 9 YZ | 6 | |
| 10# | 06502-010 | SCREW, HHC 7/16-14 X 1-1/4 | 4 | |
| 11#% | 25841 | HOUSING, SINGLE SPEED W/TACH | 1 | |
| 12#% | 162000 | BLADE SHAFT | 1 | |
| 13#% | 576005 | SNAP RING, SH-156 | 2 | |
| 14#% | 10138 | SCREW, SHS, 1/4-20 X 1/2, NP | 6 | |
| 15#% | 486000 | WASHER, THRUST | 2 | |
| 16#% | 485001 | SLEEVE, BLADE SHAFT SEAL | 2 | |
| 17#% | 480001 | SEAL, OIL CR# 26110 | 2 | |
| 18#% | 480002 | SEAL, OIL CR# 16022 | 2 | |
| 19#% | 578129 | O-RING, SIZE 2-129 BUNA 70 | 2 | |
| 20#% | 460008 | BEARING, 7208BGC3 | 2 | |
| 21#% | 460004 | BEARING, CYLINDRICAL NU2208RC3 | 1 | |
| 22#% | 11722 | FITTING, 90 6MJ-6M0 | 2 | |
| 23#% | 969314 | KEY, WOODRUFF, #61, 3/16" X 5/8" | 2 | |
| 24#% | 583026 | DRAIN PLUG, MAGNETIC, 1/2-20 | 1 | |
| 25#% | 577009 | GASKET, DRAIN PLUG | 1 | |
| 26#% | 35254 | SENDER ASM, TACHOMETER SIGNAL GENERATOR | 1..... | INCLUDES ITEMS W/+ |
| 27#% | 35077 | GEAR, SAW BLADE SHAFT SPEED PICKUP | 1 | |
| 28#% | 180001 | COLLAR ASSY., OUTER BLADE SHAFT | 2..... | INCLUDES ITEMS W/@ |
| 29#% | 180000 | COLLAR, INNER BLADE SHAFT | 2 | |
| 30#% | 582012 | BUSHING, QUICK DISCONNECT BLADE SHAFT | 2 | |
| 31#% | 915315 | SCREW, HHC 5/8-11X3 GR8 | 1 | |
| 32#% | 25695 | WASHER, SEALED 3/4" | 1 | |
| 33#% | 915316 | SCREW, HHC 5/8-11X3 LH GR8 | 1 | |
| 34#% | 576002 | SNAP RING, VH0-315 | 1 | |
| 35#%+ | 421001 | GENERATOR, TACHOMETER SIGNAL | 1 | |
| 36#%+ | 12171 | SEAL, WEATHERPACK 16-18 GA, GREEN | 2 | |
| 37#%+ | 12179 | TERMINAL, WEATHERPACK MALE 14-16 GA | 2 | |
| 38#%+ | 12176 | CONNECTOR, WEATHERPACK 2 MALE PIN | 1 | |
| 39#%+@ | 980705 | PIN, DOWEL 3/8 X 1-1/4" | 4 | |
| 40#%+@ | 180001-1 | COLLAR, BLADE OUTSIDE | 2 | |


Positraction Assy.



Positraction Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|---|-------------|---------------|
| 1 | 442019 | POSITRACTION ACTUATOR LEVER | 1 | |
| 2 | 560026 | COVER, HANDLE FLAT RED | 1 | |
| 3 | 442020 | LEVER CONNECTOR | 1 | |
| 4 | 933015 | FRICTION DISC, 1-1/2" X 1/2" X 1/8" | 1 | |
| 5 | 933073 | WASHER, BELLVIEW 1/2 X 1-1/4 | 1 | |
| 6 | 19974 | PIN, CLEVIS | 1 | |
| 7 | 965103 | PIN, COTTER 5/32 X 1 PLTD | 1 | |
| 8 | 565003 | SPRING, COMPRESSION | 1 | |
| 9 | 933244 | WASHER, FLAT SAE 1/2 GRD 9 YZ | 9 | |
| 10 | 25673 | STUD, 1/2-13 X 2" | 1 | |
| 11 | 938064 | LOCKNUT, TOP 1/2-13 YZ | 1 | |
| 12 | 168005 | POSI-TRACTON AXLE TUBE | 1 | |
| 13 | 160012 | SHAFT, POSITRACTION DRIVE | 1 | |
| 14 | 460020 | BEARING, COMPOSITE SLEEVE | 2 | |
| 15 | 576012 | SNAP RING SPIRAL | 2 | |
| 16 | 480003 | SEAL | 2 | |
| 17 | 583054 | SHIM, ARBOR- 1X1-1/2 X .093 | 2 | |
| 18 | 242000 | HUB, POSITRACTION DRIVE | 2 | |
| 19 | 15207 | KEY, 1/4 SQ X 1.5 | 2 | |
| 20 | 0655 | SCREW, HHC 5/16-18 X 3/4 | 2 | |
| 21 | 35147 | WASHER, FLAT .375 I.D. X 1" O.D. X .125 | 2 | |
| 22 | 442018 | POSI-TRAC LOWER CONNECTION LEVER | 1 | |
| 23 | 915105 | SCREW, HHC 3/8-16 X 1.0 GRD8 | 2 | |
| 24 | 933242 | WASHER, FLAT SAE 3/8 GRD 9 YZ | 2 | |
| 25 | 125035 | BRACKET, ANGLE POSI TRAC | 2 | |
| 26 | 120080 | PLATE, CLAMPING, POSI TRAC | 2 | |
| 27 | 5218 | SCREW, HHC 1/2-13 X 1 1/2 | 2 | |
| 28 | 6159A | SCREW, HHC 1/2-13 X 2 | 2 | |
| 29 | 10176 | NUT, NYLOC 1/2-13 | 2 | |
| 30 | 933225 | WASHER, FENDER 1/2 X 1-1/2 ZINC | 1 | |


Pulley and V-Belt Assy.



Pulley and V-Belt Assy.

| NO | PART NO | PART NAME | QTY. | REMARKS |
|-----------|----------------|---|-------------|------------------------------------|
| 1 | 540006 | PULLEY, BLADESHAFT 3.8 6G 3VX1615 | 1 | 16" BLADE |
| 1 | 540066 | PULLEY, BLADESHAFT 4.0 6G 3VX2012 | 1 | 20" BLADE |
| 1 | 540065 | PULLEY, BLADESHAFT 4.2 6G 3VX2012 | 1 | 26" BLADE |
| 1 | 540049 | PULLEY, BLADESHAFT 4.4 6G 3VX1615 | 1 | 30" BLADE |
| 2 | 540000 | PULLEY, ENGINE 3.8 6G 3VX4.01A | 1 | 16" BLADE |
| 2 | 540070 | PULLEY, ENGINE 3.8 6G 3VX5.01A | 1 | 20" BLADE |
| 2 | 540012 | PULLEY, ENGINE 3.0 6G 3VX4.01A | 1 | 26" AND 30" BLADE |
| 3 | 582013 | KEY, 3/8" X 3/8" SQ X 2-1/4" | 1 | |
| 4 | 582028 | BUSHING, TAPER-LOCK 1615 X 1-7/16..... | 1 | 16" AND 20" BLADE, ENGINE SIDE |
| 5 | 582020 | BUSHING, TAPER-LOCK 1615 X 1-1/2..... | 1 | 16" AND 30" BLADE, BLADESHAFT SIDE |
| 5 | 460030 | BUSHING, TAPER-LOCK 2012 X 1-1/2..... | 1 | 20" AND 26" BLADE, BLADESHAFT SIDE |
| 6 | 520006 | V-BELT, 6 3 VX 425 | 1 | ALL MODELS |
| 7 | 521005 | V-BELT, AX-31 | 2 | ALL MODELS |
| 8 | 25557 | BELT TENSIONER ASSY. | 1 | INCLUDES ITEMS W/@ |
| 9@ | 3214 | SCREW, HHC 1/2-13 X 1 1/4 | 1 | |
| 10@ | 933244 | WASHER, FLAT SAE 1/2 GRD 9 YZ | 2 | |
| 11@ | 448000 | IDLER ARM, FENNER | 1 | |
| 12@ | 544001 | ADAPTOR, SHOULDER, FENNER DRIVE | 1 | |
| 13@ | 540003 | PULLEY, W/BRG. 4" A SECTION | 1 | |
| 14@ | 25716 | SCREW, MODIFIED 1/2-13 X 1 3/4 | 1 | |
| 15 | 13016 | BELT DRIVE JACKSHAFT ASSY..... | 1 | INCLUDES ITEMS W/\$ |
| 16\$ | 540030 | PULLEY, 4.125 x .750 1A | 2 | |
| 17\$ | 925437 | SCREW, SHS,CP 5/16-18 x 3/8 | 4 | |
| 18\$ | 576003 | SNAP RING - HO-185 | 2 | |
| 19\$ | 460021 | BEARING, ROLLER # 6204 2RS | 2 | |
| 20\$ | 25845 | JACKSHAFT ARM | 1 | |
| 21\$ | 584013 | KEY, 3/16 SQ x 1.0 | 2 | |
| 22\$ | 167001 | JACKSHAFT, SAW BELT DRIVE | 1 | |
| 23\$ | 10307 | SCREW, HHC 1/2-13 X 5 | 1 | |
| 24\$ | 933244 | WASHER, FLAT SAE 1/2 GRD 9 YZ | 2 | |
| 25\$ | 960102 | FITTING, GREASE ZERK STR 1/8 MP | 1 | |
| 26\$ | 10176 | NUT, NYLOC 1/2-13 | 1 | |
| 27 | 120081 | MOUNT, TENSIONER | 1 | |
| 28 | 0205 | SCREW, HHC 3/8-16 X 1 | 2 | |
| 29 | 933242 | WASHER, FLAT SAE 3/8 GRD 9 YZ | 2 | |


Battery Assy.



Battery Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|---|-------------|---------------|
| 1 | 404000 | BATTERY, GROUP 26R | 1 | |
| 2 | 25838 | MOUNT, BATTERY CLAMP | 1 | |
| 3 | 19303 | CABLE, BATTERY POS 4 GA X 48" POST | 1 | |
| 4 | TBD | CABLE, BATTERY POS | 1 | |
| 5 | 16782 | CABLE, 24" POS | 1 | |
| 6 | TBD | CABLE, BATTERY NEG | 1 | |
| 7 | 12022 | CABLE, BATTERY NEG 4 GA X 20" X 1/2" | 1 | |
| 8 | 933242 | WASHER, FLAT SAE 3/8 GRD 9 YZ | 2 | |
| 9 | 933240 | WASHER, FLAT SAE 1/4 GRD 9 YZ | 1 | |
| 10 | 10133 | NUT, NYLOC 3/8-16 | 1 | |
| 11 | 10024 | NUT, NYLOC 1/4-20 | 1 | |
| 12 | 35023 | CLAMP, LOOM CUSHIONED #10 .263 HOLE | 1 | |
| 13 | 1023 | SCREW, HHC 3/8-16 X 1 1/4 GR 5 | 1 | |
| 14 | 12278 | CABLE, BATTERY NEG POST 4 GA X 32 X 3/8 | 1 | |
| 15 | TBD | BATTERY CABLE KIT | 1 | |


Engine Brackets Assy.



Engine Brackets Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|--|-------------|--------------------|
| 1 | 125034 | LIFTING RING | 1 | |
| 2 | 933242 | WASHER, FLAT SAE 3/8 GRD 9 YZ | 4 | |
| 3 | 915105 | SCREW, HHC 3/8-16 X 1.0 GRD8 | 4 | |
| 4 | 125016-3 | STANDOFF, LIFTING PLATE 35HP | 4 | |
| 5# | 282002 | PREFILTER, ENGINAIRE 3" 2-20/150 | 1 | |
| 6# | 300000 | AIR FILTER HOUSING, ASM | 1 | |
| 7# | 300000-1 | FILTER, AIR, ELEMENT, PRIMARY | 1 | |
| 8# | 300000-2 | FILTER, AIR, ELEMENT, SAFETY | 1 | |
| 12# | 364002 | HOSE, 2" 90 DEGREE | 1 | |
| 13# | 10434 | CLAMP, HOSE WORM 1-9/16 TO 2.0 # 32 | 1 | |
| 14# | 364003 | COUPLER, HOSE INTAKE | 1 | |
| 15# | 364000 | HOSE, 2" X 1 3/4" 90 DEGREE | 1 | |
| 16 | 280000 | MUFFLER, WISCONSIN 35, STANDARD | 1 | |
| 17 | 2534 | CLAMP, MUFFLER | 1 | |
| 20 | 25719 | NIPPLE, EXHUAST PIPE SCH 40 | 1 | |
| 21# | 35098 | CLAMP, HEAT SHRINK TUBING 2.5" - 2.75" | 1 | |
| 22# | 962015 | CLAMP, HOSE #28 1-5/16X2-1/4 | 1 | |
| 24 | 35182 | AIR INTAKE GROUP | 1 | INCLUDES ITEMS W/# |


Engine Installation Assy.



Engine Installation Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|----------------------------------|-------------|---------------|
| 1 | 15500 | ENGINE, WISCONSIN W41770-467438R | 1 | |
| 2 | 25813 | MOUNT, JACKSHAFT PIVOT ARM | 1 | |
| 3 | 120079 | MOUNT, MOTOR TENSIONER | 1 | |
| 4 | 933246 | WASHER, FLAT SAE 5/8 GRD 9 YZ | 2 | |
| 5 | 4702 | NUT, HEX FINISH 5/8-11 | 2 | |
| 6 | 06503-026 | SCREW, HHC 1/2-13 X 3-1/4 | 2 | |
| 7 | 25836 | MOUNT, ENGINE TENSIONING | 1 | |
| 8 | 913217 | SCREW, HHC 1/2-13 X 3 1/2 GR5 WZ | 2 | |
| 9 | 933244 | WASHER, FLAT SAE 1/2 GRD 9 YZ | 8 | |
| 10 | 10176 | NUT, NYLOC 1/2-13 | 4 | |


Bladeguard Assy.



Bladeguard Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|--|-------------|---------------|
| 1 | M18100 | BLADE GUARD 16-INCH | 1 | |
| 1 | M18140 | BLADE GUARD 20-INCH | 1 | |
| 1 | M18180 | BLADE GUARD 26-INCH | 1 | |
| 1 | M18220 | BLADE GUARD 30-INCH | 1 | |
| 2 | 10176 | NUT, NYLOCK | 1 | |
| 3 | 582040 | BUSHING, BLADE GUARD | 1 | |
| 3 | 582039 | BUSHING, BLADE GUARD..... | 1 | 30-INCH ONLY |
| 4 | 362000 | HOSE, WATER #6LP | 2 | |
| 5 | 923144 | SCREW, SHC 10-24X12 | 4 | |
| 6 | 362003 | TUBE, WATER, LH SIDE | 1 | |
| 7 | 1618 | NUT, NYLOCK 10-24 | 4 | |
| 9 | 933209 | WASHER, FENDER 1/4" X1-1/2" ZINC | 1 | |
| 10 | 10024 | NUT, NYLOCK 1/4-20 | 3 | |
| 11 | 200019 | FLAP, MUD | 1 | |
| 12 | 0131 A | SCREW, HHC 1/4"-20 X3/4" | 1 | |
| 13 | 445002 | WATER MANIFILD | 1 | |
| 13 | 445003 | WATER MANIFILD..... | 1 | 30-INCH ONLY |
| 14 | 5277 | SCREW, HHC 1/4"-20 X1-1/2" | 2 | |
| 15 | 36002 | TUBE, WATER, RH SIDE | 1 | |
| 16 | 320010 | FITTING, QD MALE SNAPTITE PHN4 1/4" MP | 1 | |
| 17 | 2113 | FITTING, PLUG 1/8" MP HEX SKT HD | 1 | |
| 18 | 370455 | FITTING, STR 6BARB-1/8" MP | 2 | |
| 19 | 06503-026 | SCREW, HHC 1/2-13 X3-1/4" | 1 | |
| 19 | 06503-030 | SCREW, HHC 1/2-13 X3-3/4" | 1 | |
| 20 | 320009 | FITTING, QD FEM SNAPTITE PHC4-4F | 1 | |


Optional Water Pump Kit Assy.



Optional Water Pump Kit Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|---------------------------------------|-------------|---------------|
| 1 | M18100 | BLADE GUARD 16-INCH | 1 | |
| 1 | 120084 | DESCRIPTION | 1 | |
| 2 | 120085 | MOUNT, WATER PUMP | 1 | |
| 3 | 342000 | PUMP, WATER JABSCO | 1 | |
| 4 | 933242 | WASHER, FLAT SAE 3/8 GRD 9 YZ | 4 | |
| 5 | 933244 | WASHER, FLAT SAE 1/2 GRD 9 YZ | 2 | |
| 6 | 205 | SCREW, HHC 3/8-16 X 1.0 | 4 | |
| 7 | 16524 | SCREW, HHC 1/2-13 X 1 1/4 GD 8 | 2 | |
| 8 | 369970 | FITTING, PETCOCK RAD DRAIN 1/4MP | 1 | |
| 9 | 366057 | FITTING, BRASS 1/2FP-1MP | 2 | |
| 10 | 366956 | FITTING, BRASS 1/4FP-1/2MP | 1 | |
| 11 | 25932 | FITTING, BRASS 8 PUSH-ON-1/4MP | 1 | |
| 12 | 25931 | FITTING, 90 8BARB - 1/2 MP (4390-8-8) | 1 | |
| 13 | 540032 | PULLEY, 4.12 X 2G A | 1 | |
| 14 | 521005 | V BELT, AX-31 (GOODYEAR) | 1 | |
| 15 | 35257 | HOSE, 1/2 ID PUSHLOCK 250 PSI, 18" | 1 | |
| 16 | 35258 | HOSE, 1/2 ID PUSHLOCK 250 PSI, 13" | 1 | |
| 17 | 406000 | SWITCH, ROCKER, CH# M-58031-01 | 1 | |

Collar Puller Assy.




Collar Puller Assy.

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|---------------------------------|-------------|--------------------|
| 1# | 584037 | OUTER PULLER | 1 | |
| 2# | 584038 | PLATE, PULLER | 1 | |
| 3# | 2549 | SCREW, HHC 1/2-13 X 3 | 3 | |
| 4# | 25138 | SCREW, HHC 5/8-11 X 5 TAP | 1 | |
| 5# | 18503-I | COLLAR PULLER INSTRUCTION SHEET | 1 | |
| 6 | 18503 | COLLAR PULLER | 1 | INCLUDES ITEMS W/# |

MQ SP-3035 Concrete Saw — Seal Sleeve Puller Seal/Seal Installation Tool

Seal Sleeve Puller/Seal Installation Tool




MQ SP-3035 Concrete Saw — Seal Sleeve Puller Seal/Seal Installation Tool

Seal Sleeve Puller/Seal Installation Tool

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|--|-------------|--------------------|
| 1# | 35163 | SCREW, HHC 3/8 – 16 X 4 FULL THREAD | 1 | |
| 2 | M18505 | SEAL SLEEVE & THRUST WASHER PULLER ASM | 1 | INCLUDES ITEMS W/# |
| 3# | 35162 | SCREW, 10 - 24 X 6 FULL THREAD | 2 | |
| 4# | 584052 | SEAL INSTALLATION TOOL | 1 | |
| 5# | 35161 | SCREW, 10 - 24 X 12 FULL THREAD | 2 | |
| 6# | 937980 | NUT, WELD 10 - 24 | 2 | |
| 7# | 35164 | SCREW, HHC 1/4 – 20 X 5 | 3 | |
| 8# | 35165 | SCREW, HHC 1/4 – 20 X 10 | 3 | |
| 9# | 584050 | TOOL, SEAL REMOVAL | 1 | |

Bushing Extension Kits



Bushing Extension Kits


BUSHING EXTENSION KIT 18501 (.375 — .75)

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|------------------------|-------------|---------------|
| 1 | 926949 | DOWEL PIN, 3/8 X 2-1/4 | 1 | |
| 2 | 180003-1 | OUTER COLLAR | 1 | |
| 3 | 582032 | QD BUSHING 3/8 TO 3/4 | 1 | |
| 4 | 90123445 | 5/8-11X 4 LH HEX BOLT | 1 | |
| 5 | 915319 | 5/8-11X 4 RH HEX BOLT | 1 | |

BUSHING EXTENSION KIT 18502 (.75 — 1.125)

| <u>NO</u> | <u>PART NO</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARK</u> |
|-----------|----------------|-----------------------|-------------|---------------|
| 1 | 926950 | DOWEL PIN 3/8 X 2-1/2 | 1 | |
| 2 | 180003-1 | OUTER COLLAR | 1 | |
| 3 | 582033 | QD BUSHING 3/4-1-1/8 | 1 | |
| 4 | 90123445 | 5/8-11X 4 LH HEX BOLT | 1 | |
| 5 | 915319 | 5/8-11X 4 RH HEX BOLT | 1 | |

ELECTRIC SCHEMATIC



SPECIFICATIONS

| | |
|--------------------|--|
| Engine | Wisconsin 35 hp V-4, electronic ignition, remote oil filter and above-frame remote oil drain |
| Precleaner | Centrifugal type, self-cleaning |
| Air Cleaner | Four-stage air filtration, cartridge element w/ safety element |
| Fuel Tank | 5 gallon molded tank, shutoff valve and central drain |
| Spindle Drive Belt | Single 6-groove premium quality 3V Cross-Section Powerband |
| Belt Tensioners | Single-point Spindle belt tensioner, self-adjusting rotary belt tensioners throughout for accessories |
| Blade Range | 14" to 30" |
| Max Cut Depth | 12.75" |
| Blade Guard | Extra heavy design, slip-on type, w/quick-disconnect water hoses, usable on either side, 20" standard, 16"-20"-26"-30" optional |
| Spindle Assembly | Fully-enclosed bearings and shaft, oil bath, protected seals, 1-1/2" diameter Spindle, remote protected oil fill and vent, blade usable on either side. |
| Blade Flanges | Quick-disconnect, taper-lock, 4.5" diameter collars w/ 24 water spray ports |
| Blade Flushing | Minimum water usage system, panel-mounted flow control, 24 evenly distributed water spray ports (12 per blade side) |
| Blade Control | 12-volt hydraulic raise/lower system. Joystick-controlled at the operator's panel with plunge and raise buttons located on the control joystick |
| Blade Depth Stop | Positive, heavy duty design w/ accurate depth gauge |
| Frame | Heavy gauge laser-cut steel, box design, powder coat finish |
| Lift Point | Integral balanced single-point lift |
| Balance | Rear pivot design for quick maneuverability |
| Handlebars | 3-position adjustable with in/out and storage positions, quick locks |
| Front Wheels | 6" x 3", "no maintenance" precision sealed bearings w/ extra end seals and seal protectors; no grease points |
| Rear Wheels | 11" x 3" |
| Drive System | Hydro-Gear hydrostatic powered transaxle drive w/ infinite F-N-R speed control, central joystick, remote filter. Cable control. Positraction w/ panel-mounted lever. |
| Travel Speed | Up to 225 feet per minute |
| Battery | 12 volt, group 26, 425 cold cranking amps |
| Engine Controls | Twist-lock throttle, choke, back-lit Spindle tach w/hour meter, volt meter, 3-position ignition switch |
| Electrical Wiring | Easy service loom |
| Night Light | Standard, removable, usable either side of saw |
| Front Pointer | Heavy gauge frame, 6" pointer wheel, tether rope |
| Rear Pointer | Standard, adjustable |
| Tools | 15/16" blade wrench standard |
| Unit Dimensions | 46" long, 27-3/8" wide, 41" high (handlebars in storage position, w/o blade collars) |
| Unit Weight | 975 pounds, with oil, no fuel |

OPERATION AND PARTS MANUAL

HERE'S HOW TO GET HELP

PLEASE HAVE THE MODEL AND SERIAL
NUMBER *ON-HAND* WHEN CALLING

UNITED STATES

Multiquip Corporate Office

18910 Wilmington Ave. Tel. (800) 421-1244
Carson, CA 90746 Fax (800) 537-3927
Contact: mq@multiquip.com

Mayco Parts

800-306-2926 Fax: 800-672-7877
310-537-3700 Fax: 310-637-3284

Service Department

800-421-1244 Fax: 310-537-4259
310-537-3700

MQ Parts Department

800-427-1244 Fax: 800-672-7877
310-537-3700 Fax: 310-637-3284

Warranty Department

800-421-1244, Ext. 279 Fax: 310-537-1173
310-537-3700, Ext. 279

Technical Assistance

800-478-1244 Fax: 310-631-5032

MEXICO

MQ Cipsa

Carr. Fed. Mexico-Puebla KM 126.5 Tel: (52) 222-225-9900
Momoxpan, Cholula, Puebla 72760 Mexico Fax: (52) 222-285-0420
Contact: pmastretta@cipsa.com.mx

CANADA

Multiquip

4110 Industriel Boul. Tel: (450) 625-2244
Laval, Quebec, Canada H7L 6V3 Fax: (450) 625-8664
Contact: jmartin@multiquip.com

UNITED KINGDOM

Multiquip (UK) Limited Head Office

Hanover Mill, Fitzroy Street, Tel: 0161 339 2223
Ashton-under-Lyne, Fax: 0161 339 3226
Lancashire OL7 0TL
Contact: sales@multiquip.co.uk

BRAZIL

Multiquip

Av. Evandro Lins e Silva, 840 - grupo 505 Tel: 011-55-21-3433-9055
Barra de Tijuca - Rio de Janeiro Fax: 011-55-21-3433-9055
Contact: cnavarro@multiquip.com.br, srentes@multiquip.com.br

© COPYRIGHT 2006, MULTIQUIP INC.

Multiquip Inc and the MQ logo are registered trademarks of Multiquip Inc. and may not be used, reproduced, or altered without written permission. All other trademarks are the property of their respective owners and used with permission.

This manual MUST accompany the equipment at all times. This manual is considered a permanent part of the equipment and should remain with the unit if resold.

The information and specifications included in this publication were in effect at the time of approval for printing. Illustrations are based on the SP3 "Street Pro" Professional Slab Saw. Illustrations, descriptions, references and technical data contained in this manual are for guidance only and may not be considered as binding. Multiquip Inc. reserves the right to discontinue or change specifications, design or the information published in this publication at any time without notice and without incurring any obligations.

Your Local Dealer is:



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>