


REMINGTON MONEY BACK OFFER

If within 30 days after you have purchased your Remington® product, you are not satisfied and would like a refund, take back the product and sales slip indicating purchase price and date of purchase to the retailer from whom the product was purchased. Remington® will reimburse all retailers who accept the product within 30 days from the date of purchase. If you have any questions concerning the money back guarantee, please call 800-736-4648 in the U.S.

 **Questions or Comments:**
Please call 800-736-4648 in the U.S.

 Visit us at www.remington-products.com

 This product will bear one or more compliance marks, Listed by Underwriters Laboratories, Inc.



120-240 VAC 50/60Hz

Remington and Protect & Shine are trademarks of Remington Products Company, L.L.C.
Teflon® is a registered trademark of E. I. du Pont de Nemours Company and is used under license by Remington Products Company, L.L.C.
© 2003 R.P.C., L.L.C. Job #WPC03-121 11/03 Part No. 15050

Remington Products Company, L.L.C.
60 Main Street
Bridgeport, CT 06604

MADE IN CHINA

IMPORTANT INFORMATION

- Always heat the unit with the locking switch in the UNLOCK  position. NEVER heat the unit when the locking switch is in the LOCKED  position.
- Hold unit only by the handle; other areas get hot when in use.
- DO NOT use an abrasive cleaning fluid or material to clean the plates, as damage will occur. After the unit has cooled, wipe the plates with a damp cloth.
- DO NOT scratch the surface of the plates, as this will diminish the effectiveness of the non-stick Teflon® plus Ceramic and Ionic coating.
- The red indicator light is for power supply indications only - this is not to show when the unit is ready to use.
- DO NOT get the unit too close to scalp, face, ears, neck or skin.
- After use, allow unit to cool completely before storing.

ADDITIONAL INFORMATION**Locking Switch**


To lock the straightener in the closed position for travel or storage, squeeze the plates together and turn the locking switch clockwise. Make sure to unlock the appliance before plugging it in the next time. Simply turn the locking switch counter-clockwise to unlock it.

DUAL VOLTAGE USE

This product contains a special electronic circuit. This circuit automatically adjusts to worldwide voltage. When traveling overseas, this product can be plugged into any voltage outlet without your having to adjust the product manually in any way. In some overseas countries, an attachment plug adapter of the proper configuration for the power supply receptacle may be required. **DO NOT USE** a voltage converter or extension cord with this product.

STRAIGHTENING YOUR HAIR

Take extra care when using a Professional Straightening iron. It is important to set the correct temperature for your hair type before styling to prevent damage to the hair.

- Make sure the locking switch is in the unlocked  position.

- Select desired temperature setting. **Start with a low setting and gradually increase heat as needed based on hair type.**
- Plug in the unit. The ON indicator will glow red, and in a few minutes it will be ready for use.
- Hair should be completely dried before using a straightening iron.
- To make styling easier, use clips to section your hair: top, sides, and back.
- Always start from the back of your neck, continue over the sides and finish with the front section.
- Take a small section of hair and pull it taut. Holding the appliance with the other hand, start at the roots and clamp the hair firmly between the plates.
- With the plates clamped together, run the straightener down the entire length of hair, from roots to ends, without stopping.
- Repeat until the desired amount of straightening has been achieved.

WARNING: The plates of this professional straightener will get very hot within a few seconds. Do not touch the plates or let them come in contact with the skin once the straightener has been turned on.

Maintenance

USER MAINTENANCE INSTRUCTIONS

Make sure the unit is unplugged and cool. Clean the outside of the power handle with a slightly damp cloth. Wipe the plates with damp cloth. No other maintenance is required.

STORAGE

When not in use, unplug the unit. Allow it to cool, empty tank and store out of reach of children in a safe, dry location.

Never wrap the cord around the appliance since this will cause the cord to wear prematurely and break. Handle cord carefully, and avoid jerking, twisting or straining it especially at plug connections.

REMINGTON®

PROTECT & SHINE™

PROFESSIONAL STRAIGHTENER
with 3X protection



Teflon®
+ Ceramic
+ Ions

for beautiful, healthy,
shiny hair

S-3000i

Use & Care Guide

IMPORTANT SAFEGUARDS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING. KEEP AWAY FROM WATER.

DANGER!

As with most electrical appliances, electrical parts are electrically live even when the switch is off.

TO REDUCE THE RISK OF DEATH BY ELECTRIC SHOCK:

1. Always unplug this appliance immediately after using.
2. Do not use while bathing or in a shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in or drop into water or other liquid.
5. Do not reach for an appliance that has fallen into water. Unplug immediately.

WARNING

TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE, OR INJURY TO PERSONS:

1. This appliance is for household use only.
2. An appliance should never be left unattended when plugged in.

3. Close supervision is necessary when this appliance is used by, on, or near children or invalids.
4. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Remington.
5. Never operate this appliance if it has a damaged cord or plug; if it is not working properly; if it has been dropped, damaged, or dropped into water. If any of these things happen, return the appliance to the Remington Customer Service Center for examination and repair.
6. Keep the cord away from heated surfaces. **Do not wrap the cord around the appliance.**
7. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, etc.
8. Do not place the heated unit directly on any surface while it is hot or plugged in.
9. Never use while sleeping.
10. Never drop or insert any object into any opening or hose.
11. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
12. The plates of this appliance are hot when in use. Do not let eyes and bare skin touch heated surfaces.
13. Do not touch hot surfaces of this appliance. Use handles or knobs.
14. While emitting steam, this appliance may cause burns if it is used too close to the skin, scalp or eyes, or if it is used incorrectly.
15. To reduce the risk of contact with hot water emitted from steam vents, test unit before each use by holding it away from body and operating.
16. Fill reservoir with water only.

17. Before plugging in, read the information about dual voltage contained in the instruction section of this manual.
18. Do not use with a voltage converter, or extension cord.
19. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.



KEEP AWAY FROM CHILDREN

SAVE THESE INSTRUCTIONS

Download from www.Somanuals.com. All Manuals Search And Download.

Thank you for purchasing the Remington® Professional Straightener. This unique straightener combines optimum styling features with an exclusive Teflon® plus ceramic coating and ions to provide your hair the ultimate protection and superior shine. Please carefully read the instructions contained in this leaflet, and keep them in a safe place for future reference.

Key Features

3X Protection: Protect & Shine™ products from Remington® have an exclusive Teflon® plus Ceramic coating and ions for the ultimate defense against damage – for superior shine.

Teflon® coating: Non-stick Teflon® coating glides through any type of hair, preventing static, stickiness and build-up of mousses, gels, and hair sprays for smooth, shiny results – every time!

Ceramic coating: Ceramic protects against damaging hot spots with high, even heat to lock in moisture and create long-lasting styles.

Ionic conditioning: Negative ions are created, which neutralize positive ions to reduce static and the “frizzies,” leaving your hair looking shiny and healthy.



1. 284-375 degrees Fahrenheit variable temperature control; versatile straightening for all hair types
2. Fast heat-up, ready for use in 3-4 minutes
3. Detachable comb guides, detangles and smooths
4. ON indicator light
5. Extra large plates with Teflon® plus Ceramic coating
6. Pressure grip, scissor-action handle
7. Hang-up loop
8. Professional-length (9ft) cord
9. Locking switch
10. Ions

Full Two-Year Warranty

Remington Products Company, L.L.C. warrants this product against any defects that are due to faulty material or workmanship for a two-year period from the original date of consumer purchase. This warranty does not include damage to the product resulting from accident or misuse.

If the product should become defective within the warranty period, we will repair it or elect to replace it free of charge. We will return your product, transportation charges prepaid, provided it is delivered prepaid to: Remington Products Company, L.L.C., 60 Main Street, Bridgeport, CT 06604, Attention: Service Department. Include a letter stating the reason for the return. **KEEP SALES RECEIPT AS PROOF OF PURCHASE FOR WARRANTY PURPOSES.**

REMINGTON SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES.

This warranty gives you specific legal rights and you may also have other rights that vary from state to state. Some states do not allow the exclusion or limitation of incidental, special or consequential damages.

Product Features

Warranty Service

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>