



# WICKER DOLL BUGGY

**Assembly Instructions. Adult Assembly Required. Save these instructions for future use. This item is a toy for dolls only. For children ages (3) years and older.**



*Actual product may vary slightly from shown.*

**PRODUCT MODEL NUMBER:**  
**00569**

---

Visit us online at [www.badgerbasket.com](http://www.badgerbasket.com)

Toll-Free Customer Service: 1-800-236-1310 (Monday to Thursday 7:30 AM-4:30 PM CST)

**Web:** <http://www.badgerbasket.com/parts> • **E-mail:** [parts1@badgerbasket.com](mailto:parts1@badgerbasket.com)

**PLANT AND GENERAL OFFICE:** PO Box 227, Edgar, WI 54426-0227 • Phone: 715-352-2311 • Fax: 715-352-3163

**CORPORATE OFFICE:** 111 Lions Dr., Suite 220, Barrington, IL 60010

# PARTS AND HARDWARE:

## BEFORE YOU BEGIN ASSEMBLY:



Check all parts and hardware listed. If anything is missing or you have questions, please DO NOT call the store or return the product to them.

Contact us for assistance. Most problems are resolved without you needing to leave home. When emailing or calling us, please have this instruction manual and your product model number ready. For fastest service, go to <http://www.badgerbasket.com/parts>

## TOOLS NEEDED:

Philips Screwdriver  
Standard Screwdriver


*A power screwdriver is helpful but be careful not to strip the screws or damage the product.*

## PARTS INCLUDED:

- (A) 1 - Handle
- (B) 2 - Handle Frames
- (C) 2 - Short Screws
- (D) 1 - Wicker Body
- (E) 8 - Long Bolts
- (F) 8 - Washers
- (G) 12 - Cap Nuts
- (H) 2 - Chassis Frames
- (I) 2 - Axles
- (J) 4 - Short Bolts
- (K) 4 - Wheels
- (L) 1 - Fabric Liner
- (M) 1 - Fabric Sheet
- (N) 1 - Mattress Pad



Hardware not to scale.



## CARE INSTRUCTIONS:

Wipe clean with a damp cloth and mild soap as needed. Never immerse the basket, chassis, or mattress pad in water. The fabric liner and sheet are poly/cotton. For longevity of the product, we recommend spot cleaning or gently hand washing as needed; however you can machine wash the fabric parts in cold water, gentle cycle and air dry or tumble dry on low if desired.





**NOTE:** The “②” symbol indicates that this step is easier if you have another person assist you.

**STEP 1 - PICTURE 1:** Attach the HANDLE (A) to the HANDLE FRAMES (B) using TWO SHORT SCREWS (C).



② - **STEP 2 - PICTURE 2:** Decide if you want the handle attached in front of the carriage or behind it (it can be removed and reattached, by an adult, in the other position at any time).

Attach the TWO HANDLE FRAMES (B) to the WICKER BODY (D) using FOUR LONG BOLTS (E), FOUR WASHERS (F), and FOUR CAP NUTS (G). The bolts with washers go through the holes inside of the wicker body, and then secure the parts together on the outside of the body using the cap nuts.




② - **STEP 3 - PICTURE 3:** Attach the TWO CHASSIS FRAMES (H) to the WICKER BODY (D) using FOUR LONG BOLTS (E), FOUR WASHERS (F), and FOUR CAP NUTS (G). The bolts with washers go through the holes inside of the wicker body, and then secure the parts together on the outside of the body using the cap nuts.

**STEP 4 - PICTURE 4:** Attach the TWO AXLES (I) to the underside of the CHASSIS FRAMES (H) using FOUR SHORT BOLTS (J), and FOUR CAP NUTS (G). The bolts go through the bottom, and then secure the parts together on the top using the cap nuts. The axles face the inside.



**STEP 5 - PICTURE 5:** Attach the FOUR WHEELS (K) to the AXLES (I). Squeeze the metal clip on the wheel to open it, slide the wheel onto the axle, and then release the clip so that it locks over the end of the axle. Gently tug each wheel to make sure the clip has popped into place and locked onto the axle.



**STEP 6 - PICTURE 6:** Dress the FABRIC LINER (L) onto the WICKER BODY (D). Secure it with the ribbons (slip one or both of the ribbons, as needed, through holes in the wicker and then tie the ribbons into a bow). Dress the FABRIC SHEET (M) onto the MATTRESS PAD (N) and place them inside of the WICKER BODY (D). Your carriage is now assembled!



**WARNING !! CHOKING HAZARD! SMALL PARTS!**  
Not for children under three (3) years of age. Please make sure children know that this toy is for dolls and stuffed animals only.

**It is not to be used with real infants or with pets. Children should NEVER attempt to climb inside of it, sit in it, or stand on it.**

**Regularly check the hardware to ensure it remains tight!**



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>