


...can save a life!

INTERRUPTERS
CIRCUIT
FAULT
GROUND

This message about...



infinitiPRO
by **CONAIR**
Secador de 1875 vatios
con motor AC de
desempeño profesional



Instrucciones
Modelos 270

Your dryer is virtually maintenance free. No lubrication is needed. For proper operating performance, the dryer must be kept clean. When cleaning is needed, unplug the cord, allow to cool and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the dryer should be wiped clean with a cloth only.

USER MAINTENANCE

*GFCI is a sensitive device which reacts immediately to a small electric current leak by stopping the electricity flow.

A GFCI can save your life! Compared to that, the price is small! Don't wait...install one now!



WHY DO YOU NEED A GFCI? Electricity and water don't mix. If your hair dryer falls in water while it's plugged in, the electric shock can kill you... **even if the switch is "off."** A regular fuse or circuit breaker won't protect you under these circumstances.

A GFCI offers you far greater protection. If the cord or dryer is damaged or does not operate properly, return it for repair to an authorized Conair service representative only. No repairs should be attempted by the consumer. **Blocked or clogged air intake vents will cause the dryer to overheat.** If overheating occurs, an automatic safety device will shut the dryer or the heat off to prevent damage or personal injury. If the unit or the heat turns off, unplug the cord and allow the dryer to cool for 10 to 15 minutes before restarting. Make sure the air vents are clean.

IF YOU MUST USE YOUR HAIR DRYER IN THE BATHROOM, INSTALL A GFCI NOW! Your local electrician can help you decide which type is best for you—a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCI's in the bathrooms, garages, and outdoor outlets of all new homes.

When not in use, your dryer should be disconnected, allowed to cool and stored in a safe, dry location, out of reach of children. Do not wrap line cord around dryer. Allow the cord to hang or lie loose and straight at the point of entry into the dryer.

STORAGE - Important

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the dryer. Damage will occur at the high flex point of entry into the dryer, causing it to rupture and short. Inspect the cord frequently for damage. **Stop use immediately if damage is visible or unit stops or operates intermittently.**

CAUTION

If the cord or dryer is damaged or does not operate properly, return it for repair to an authorized Conair service representative only. No repairs should be attempted by the consumer. **Blocked or clogged air intake vents will cause the dryer to overheat.** If overheating occurs, an automatic safety device will shut the dryer or the heat off to prevent damage or personal injury. If the unit or the heat turns off, unplug the cord and allow the dryer to cool for 10 to 15 minutes before restarting. Make sure the air vents are clean.

California residents need only provide proof of purchase and should call 1-800-366-0937 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 48 months from the date of manufacture. ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 48 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. **FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.**

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.


CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.

CONSUMER NOTICE: THIS WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE. THE WARRANTY DOES NOT COVER THE DRYER'S PERFORMANCE OR THE QUALITY OF THE DRYER'S FINISH. THE DRYER IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP AT THE TIME OF PURCHASE.



Model CS710
Straightener



Model 259
Dryer

TRY OUR OTHER INFINITI PRO BY CONAIR™ PRODUCTS

GARANTÍA LIMITADA DE CUATRO AÑOS

Conair reparará o reemplazará (a su opción) su aparato sin cargo por un período de 48 meses a partir de la fecha de compra si presentara defectos de materiales o fabricación.

Para obtener servicio técnico bajo esta garantía, regrese su aparato al Centro de Servicio indicado a continuación, junto con su recibo de compra y un cheque o giro postal de US \$7.00 por gastos de manejo y envío. Los residentes de California sólo necesitan dar una prueba de compra y deben llamar al 1-800-366-0937 para recibir instrucciones de envío. En ausencia del recibo de compra, el período de garantía será de 48 meses a partir de la fecha de fabricación.

CUALQUIER GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 48 MESES DE LA PRESENTE GARANTÍA ESCRITA. Algunos Estados no permiten limitaciones sobre la duración de una garantía implícita, de modo que las limitaciones mencionadas pueden no regir para usted. **CONAIR NO SERÁ RESPONSABLE EN NINGÚN CASO POR ALGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O CUALQUIER OTRA GARANTÍA, EXPRESA O IMPLÍCITA.** Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted.

Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varían de un Estado a otro.

Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted.

Download from [Www.Somanuals.com](http://www.Somanuals.com). All Manuals Search And Download.

pelusas de las aberturas de aire con un cepillo pequeño o el cepillo accesorio de una aspiradora. La superficie exterior del secador sólo se debe limpiar con un paño limpio.

El secador se recalentará si las aberturas de aire estuvieran bloqueadas u obstruidas. Si esto ocurriera, un sistema de seguridad apagará el secador o cortará la temperatura automáticamente para evitar daños al aparato o heridas. Si esto sucediera, desenchufe el aparato y permita que enfríe durante 10 a 15 minutos antes de encenderlo de nuevo. Asegúrese de que las ventilaciones de aire estén limpias.

PRECAUCIÓN

NUNCA jale, retuerza ni doble mucho el cable. Nunca lo enrolle con fuerza alrededor del aparato. Esto podría dañar la junta flexible que lo conecta al aparato, produciendo su ruptura o un cortocircuito. Inspeccione el cable con frecuencia para asegurarse de que no esté dañado. **Deje de usar el aparato inmediatamente si el cable parece dañado o si el aparato dejara de funcionar o funcionara de manera intermitente.**

Si el cable o el aparato estuviesen dañados o si el aparato no funcionase correctamente, regréselo a un centro de servicio autorizado. No trate de repararlo.

ALMACENAJE – Importante

Después de usar el aparato, desconéctelo, permita que enfríe y guárdelo en un lugar seco y seguro, fuera del alcance de los niños. No enrolle el cable alrededor del aparato. Permita que el cable cuelgue o que la junta que lo conecta al secador esté suelta y recta.

10PD117078 **IB-10345**

For info on any Conair or Infiniti by Conair product call: **1-800-3-CONAIR** or visit us on the web at: www.conair.com/infiniti

©2011 CONAIR CORPORATION

Glendale, AZ 85307

7475 N. Glen Harbor Blvd

Service Department

CONAIR CORPORATION

Service Center

Please register this product at: www.conair.com/registration



¡SI DEBE USAR EL SECADOR EN EL CUARTO DE BAÑO, INSTALE UN GFCI* AHORA!

Su electricista le puede ayudar a decidir cual sistema escoger – un sistema amovible que se conecta al tomacorriente o un sistema permanente que él instalará. El Código Nacional de Electricidad ahora exige que todos los enchufes ubicados en los cuartos de baño, los garajes y las partes exteriores de las casas nuevas sean equipados con GFCI.

¿POR QUÉ NECESITA UN GFCI? La electricidad y el agua no deben juntarse. Si su aparato cayera al agua mientras esté conectado, una descarga eléctrica podría causar su muerte. . . **aunque el interruptor esté apagado.** Un fusible o un interruptor de circuito regular no le protegerá en esta situación. Un GFCI ofrece más protección.



¡Un GFCI puede salvar su vida! ¡Comparado con ella, el precio es bajo! ¡No espere... instale uno ahora mismo!

*Un GFCI es un dispositivo sensible que reacciona inmediatamente a una pequeña pérdida de corriente, deteniendo el flujo de electricidad.

INSTRUCCIONES DE MANTENIMIENTO

Su secador requiere poco mantenimiento. No necesita lubricación. Para que funcione correctamente, debe mantenerlo limpio. Cuando sea necesario limpiarlo, desconéctelo, permita que enfríe y saque el polvo y las

Model 270 **Instruction & Styling Guide**



INFINITI! PRO
by **CONAIR**
1875 Watt
Salon Performance
AC Motor
Styling Tool



Este mensaje sobre los ...

GROUND
FAULT
CIRCUIT
INTERRUPTERS

(Interruptores de circuito contra fallas a tierra)... puede salvar una vida!

10PD117078

IB-10345

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>