

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

DANGER

— Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing or in a shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquid.
5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

WARNING — To reduce the risk of burns, electrocution, fire, or injury to persons:

1. **This appliance should never be left unattended when plugged in.**
2. This appliance should not be used by, on, or near children or individuals with certain disabilities.

3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

4. Do not use an extension cord to operate appliance.

5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.

6. Keep the cord away from heated surfaces.

7. Do not pull, twist, or wrap line cord around appliance, even during storage.

8. Never place the appliance on a soft surface, such as a bed or couch, where the air openings may be blocked.

9. Never use while sleeping.

10. Never drop or insert any object into any opening.

11. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

12. This curling iron and clip are hot when in use. Do not let heated surfaces touch eyes or bare skin.

13. Do not place the heated iron directly on any surface or on the appliance power cord while it is hot or plugged in. Use the built-in counter rest.

14. Do not touch the hot surface of this appliance. Use the handles or knobs.

15. Before plugging in read the information about dual voltage in the instruction section of this manual.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This straightening and curling iron appliance is intended for household use. This unit is designed to operate at 120/240 volts AC. Use on Alternating Current (50/60 hertz) only.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

DUAL VOLTAGE

This straightening and curling iron will automatically adjust to the proper voltage. Use an adapter plug with correct configuration, prior to use in outlet.

GETTING STARTED

Your new iron is a 2-in-1 split barrel iron that can be used to curl or straighten. The iron's 25 temperature settings and Instant Heat

technology combined provide styling versatility for all hair textures. If you have fine hair, a low temperature will provide the best results. If you have thick, wavy or hard-to-curl or straighten hair, keep the heat setting high. You can vary the iron's temperature according to your particular need!

To achieve faster styling results, we have added a unique optional Turbo Heat™ on/off feature. Press the Turbo button to deliver up to 20°C/68°F more heat in the highest setting, for maximum styling performance.

To begin, plug the curling iron cord into any household outlet (120/240V). Press the ON/OFF button and the red indicator light will blink. When ready to use, the red indicator light will remain on. Press the turbo button and the green indicator light will come on. Press ON/OFF button again and the red and green lights will go off. Never leave you curling iron on and unattended. However, should you fail to turn the iron off, it will shut itself off automatically within 60 minutes.

STRAIGHTENING WITH THE NEW INSTANT HEAT 2-IN-1 SPLIT BARREL PLATES

The plates of your new iron have an extra-smooth surface, for maximum straightening performance.

You'll find that hair glides easily over the surface of the plates as you're straightening and it's simpler to clean off styling product residue after each use.

The ceramic surface also helps smooth down flyaways and frizzies. As you smooth each

strand, heat is evenly distributed so that the style you create has a salon-perfect, silky smooth, shining finish. Hair slips right off the plates after it's straightened.

The ceramic technology makes styling your hair easier and the results more professional.

STRAIGHTENING BASICS

1. Be sure locking mechanism on cool tip is released to open barrel for straightening.
2. Section hair evenly and comb each section.
3. Place hair section between plates and press together.
4. Slowly guide plates down hair strand. Repeat as necessary until hair strand is smooth.

CURLING WITH THE EASY-GLIDE CERAMIC-COATED BARREL

The barrel of your new iron has a Easy-Glide™ ceramic-coated surface.

The ceramic-coated surface also helps smooth down flyaways and frizzies while curling. As you wind each strand around the barrel, it evenly distributes heat so that the style you create has a salon-perfect, silky smooth, shining finish. Hair slips right off the barrel after it's curled as well.

The ceramic technology is a pleasure to work with and makes styling your hair easier and the results more professional.

CURLING BASICS

1. Be sure the locking mechanism on cool tip is locked to keep barrel closed while curling.
2. Section dry hair evenly, and comb each section before winding. Pressing the automatic curl release, place curling iron midway up the hair section, then spread hair evenly between spoon and barrel. Release automatic curl release to hold hair in place. Gently slide curling iron down to hair ends. To avoid crimped ends, make sure they are securely wound under the spoon in the direction of the desired curl. Remember, always place the spoon above the hair strand when making a curl you want rolled under; place the spoon under the hair strand when making a flip style.

3. Wind the hair up as far as you want it curled, being careful not to let the iron touch the scalp. Hold in place for 8-12 seconds depending on the texture and length of your hair. For tighter, bouncier curls, roll less hair. For looser, free-flowing curls, roll more hair.

4. When finished, unwind the hair and press the automatic curl release. To set the curl, do not comb or brush through hair until it cools.

USING INSTANT HEAT, THE 25 VARIABLE TEMPERATURE SETTINGS & UNIFORM HEAT RECOVERY SYSTEM

This styling iron features Conair's Instant Heat technology. Within this Instant Heat technology there are 25 variable temperature settings. Every type of hair, from the finest to the curliest and most resistant, has a temperature range that's gentle and safe for it and helps you create the look you want.

Temperature Setting Guide

TEMP. CONTROL	HAIR TYPE
Low 1-8	Delicate, thin, easy-to-style hair
Medium 9-14	Average to thick or treated hair
Med-High 15-20	Thick or wavy hair
High 21-25	Hard-to-style hair
Turbo Heat™	Up to 20°C/68°F burst of heat for difficult styling spots

And that's not all. Conair's professional salon standards of engineering provide you with a Uniform Heat Recovery System that maintains the iron at constant temperatures.

There is a constant flow of power to ensure that heat is continuously delivered for optimal styling results, unlike other units which lose heat during use. This provides consistent styling power so that every strand of your hair is set with the same level of heat and comes out the same way for a perfect finish.

GET TO KNOW YOUR 2-IN-1 SPLIT BARREL STRAIGHTENER & CURLING IRON



USER MAINTENANCE

Your straightener/curling iron is virtually maintenance-free. No lubrication is needed. If cleaning becomes necessary, disconnect it from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the straightener/curling iron, allow it to cool and return it for repair to an authorized service center only. No repairs should be attempted by the consumer.

CAUTION

NEVER allow the power supply cord to be pulled or twisted. Never wrap the cord around the straightener/curling iron. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.


STORAGE

When not in use, your appliance should be disconnected, allowed to cool and stored in a safe, dry location out of reach of children. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

WARNING: The instant heat barrel will get very hot within a few seconds and should not be placed in contact with skin after the curling iron is turned ON. The special application of this straightener/curling iron will result in an extremely hot barrel when the high setting is chosen. Always do a test curl before using the iron to ensure the proper setting for your hair type.

**WARNING:
IF YOU THINK
THE POWER IS OFF
WHEN THE SWITCH
IS OFF,
YOU'RE WRONG.**

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG
SMALL APPLIANCES**

LIMITED TWO-YEAR WARRANTY

Conair will repair or replace, at our option, your appliance free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below, together with your sales slip and \$3.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION OF THIS WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

SERVICE CENTER
CONAIR CORPORATION
Service Department
150 Milford Road
East Windsor, NJ 08520

©2006 CONAIR CORPORATION
www.conair.com
06PC2048

IB-6493

Instant Heat



2-in-1 Straightener & Curling Iron

Instruction & Styling Guide

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

CONAIR®

Model CD86JCS

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>