


iHome.FIT


Model: iB11

Sport Ear Buds with Detachable Ear Hooks and In-Line Volume Control



Cord Management

The hang tag at this top of the package also functions as a convenient cord management device. Pass the headphone plug through the opening in the hang tag as shown and then wind the headphone cord around the hang tag. This will keep your headphone cord tangle free and always ready to use.




Using Your iHome FIT Sport Ear Buds

Your ear buds are assembled into the ear hooks at the time of purchase. You may use the ear buds together with the hooks for a more secure fit while performing strenuous exercise, or detach the ear buds from the hooks when the hooks are not required.

The earpieces are marked "L" and "R". Place the "L" earpiece in your left ear and the "R" earpiece in your right ear for proper fit and best sound. If the earpieces are inserted incorrectly they will not fit properly in your ears and the sound quality will not be satisfactory. Some users may place the hooks over their ears first and then insert the tips in their ears. Others may find it easier to place the tips in their ears first and then position the soft rubber hooks over their ears. Either method is acceptable.


NOTE: When using this model without the hooks you have two options:

Option A – You may still route the cables up and over your ears as shown in the following illustration:





Option A

Option B: If you prefer not to have the cable routed over your ears you may choose to have the cable extend directly downward from your ears. In this case should place the 'L' bud in your right ear and the 'R' bud in your left ear, as shown in the following illustration.



Option B

Your iHome FIT Sport Ear Buds are supplied with three sets of silicon tips (S, M and L). The 'M' size tips were installed at our factory. If you find that the 'M' size tips are either too large or too small for your ears you may change to the 'S' or 'L' size tips. To change the tips, carefully pull the installed tips off the earpieces and push the new tips on to the earpieces as shown in the illustration



IMPORTANT: Make sure that the new tips are fully seated on the earpieces so that the tips do not come off when you remove the earpieces from your ears. If one of the tips remains in your ear canal and you cannot easily remove it, seek medical attention to avoid forcing the tip further into your ear canal.

Using the In-Line Volume Control

You may have to adjust the volume control on your music player as well as the In-Line Volume Control on your headphones to find the most satisfactory sound level. If one control is set too low and the other is set too high, the sound may be distorted. Try setting the volume control on your music player halfway between the Min and Max settings, and then use the In-Line Volume Control on your iHome FIT headphones to make final adjustments.

The volume control includes a convenient clothing clip to secure the cable to your clothing while jogging or exercising.

Safety Information

To protect your hearing, always start listening with the Volume Control of your music player set to a low level and gradually increase the volume to a comfortable listening level.

IMPORTANT! Listening at high volume for long periods of time can result in long-term hearing damage. For your safety, do not use headphones if they would prevent you from hearing warning sounds, such as while driving a car or motorcycle, riding a bike, etc.

NOTE: In extremely cold or dry air conditions you may notice a slight 'tingling' feeling in your ears when using in-ear headphones. This is the result of the build-up of static electricity in your body. This is normal and not an indication of any problem with your headphones.

Limited Lifetime Warranty Information

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for the lifetime of the product from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by SDI Customer Service. The product must include proof of purchase, including date of purchase. An out-of-warranty fee for service will be charged for units that are received without proof of purchase.

Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered. If service is still required:

1. Call SDI Customer Service at 1-800-288-2792 for Return Authorization and for the address of the Factory Service Center.
2. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box. SDI is not responsible for damage that occurs during shipping to the Factory Service Center.
3. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period. Also include your name and address information, a brief description for why the unit is being returned, and the return authorization number. No unit can be processed without a return authorization number.
4. Write the return authorization number on the side of the shipping package and send the unit prepaid and insured to the Factory Service Center address authorized by SDI Customer Service.

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI or any of its affiliates, contractors, resellers, their officers, directors,

shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI product.

© 2013 SDI Technologies, Inc. All rights reserved

Questions? Visit www.ihomeaudio.com or call 1-800-288-2792 Toll Free.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>